


F.A.Q's for TEW-432BRP


Q: How do I change the password on my router?

Step 1 Log into the router by entering it's IP address into a browser. The default IP address is <http://192.168.1.1>. The default username is admin with a password of admin.

Step 2 Click "Main" on the left hand side then click on "Password" at the top of the page.



Q: What can I do if I forgot my password or want to reset back to factory defaults?




Press and hold in the reset button on the back of the router for approximately 15 seconds.

Q: How do I save or reload the configuration of my router?

Step 1 Log into the router by entering it's IP address into a browser. The default IP address is <http://192.168.1.1>. At the login, enter your username (admin) and password (admin).


Step 2 Click "Tool" on the left hand side then click on "Settings" at the top of the page.



Q: How do I upgrade the firmware on my router?

Step 1 Log into the router by entering its IP address into a browser. The default IP address is <http://192.168.1.1>. At the login, enter your username (admin) and password (admin).

Step 2 Click “Tools” on the left hand side then click on “Firmware” at the top of the page.



Step 3 Click on “Browse” next to the box under the Upgrade Firmware section. Locate and select the firmware file then click “Upgrade”.

It will take approximately 30 seconds to upgrade the firmware and the access point to restart.


Q: What is the default IP address of my router?

The default IP address is <http://192.168.1.1>. The default username is (admin) and the default password is (admin).

Q: How do I change the IP address of my router?

Step 1 Log into the router by entering its IP address into a browser. The default IP address is <http://192.168.1.1>. At the login, enter your username (admin) and password (admin).

Step 2 Click “Main” on the left hand side then click on “LAN&DHCP Server” at the top of the page.



Step 3 Enter in the new value for IP Address and click “Apply”.


Q: How do I configure the router through the web-based configuration?

Step 1 Log into the router by entering it’s IP address into a browser. The default IP address is <http://192.168.1.1>. At the login, enter your username (admin) and password (admin).

Q: How do I enable encryption on my router?

Step 1 Log into the router by entering it’s IP address into a browser. The default IP address is <http://192.168.1.1>. At the login, enter your username (admin) and password (admin).

Step 2 Click on “Wireless” on the left hand side then click on “WEP” at the top of the page.




Step 3 Enter in the desired encryption values then click “Apply”.

Q: Where can I find the MAC address of my router?

Step 1 Log into the router by entering its IP address into a browser. The default IP address is <http://192.168.1.1>. At the login, enter your username (admin) and password (admin).

Step 2 Click “Status” on the left hand side then click on “Device Information” at the top of the page.



C:\My Web Sites\tew-432brp\192.168.1.1\status.htm - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Back Forward Stop Home Search Favorites Print Mail News RSS H Links Help Desk HowardForums Wells Fargo

Address C:\My Web Sites\tew-432brp\192.168.1.1\status.htm

Google Search PageRank No popups Check AutoLink AutoFill Options

TRENDnet
TRENDnet USA
What's Next in Networking

54Mbps 802.11g Wireless Firewall Router TEW-432BRP

Device information ▶ Log ▶ Log Setting ▶ Statistic ▶ Wireless **HELP**

Firmware Version: 1.0.0 , Thu, 28 Jul 2005

LAN	
MAC Address	00-40-f4-dd-88-72
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
DHCP Server	Enabled DHCP Table


Wireless	
MAC Address	00-40-f4-dd-88-72
SSID	default
Channel	6
WEP	Disable

My Computer

Q: How do I forward ports in my router?

Well Known Ports

- 1) Log into the router by entering its IP address into a browser. The default IP address is <http://192.168.1.1>. At the login, enter your username (admin) and password (admin).
- 2) Click on **Cancel** if the Setup Wizard comes up.
- 3) Click on **Access** on the left hand side.
- 4) Click on **Virtual Server** at the top of the page.



54Mbps 802.11g Wireless Firewall Router TEW-432BRP

Mac Filter ▶ Protocol Filter ▶ IP filter ▶ **Virtual Server** ▶ Special AP ▶ DMZ ▶ Firewall Rule ▶ HELP

Enable Enable Disabled

Name: Virtual Server FTP

Protocol: TCP

Private Port: 21

Public Port: 21

LAN Server: 192.168.1.15


add Update Delete Clear

	Name	Protocol	LAN Server
<input checked="" type="checkbox"/>	Virtual Server FTP	TCP 21/21	0.0.0.0
<input type="checkbox"/>	Virtual Server HTTP	TCP 80/80	0.0.0.0
<input type="checkbox"/>	Virtual Server HTTPS	TCP 443/443	0.0.0.0
<input type="checkbox"/>	Virtual Server DNS	UDP 53/53	0.0.0.0
<input type="checkbox"/>	Virtual Server SMTP	TCP 25/25	0.0.0.0
<input type="checkbox"/>	Virtual Server POP3	TCP 110/110	0.0.0.0
<input type="checkbox"/>	Virtual Server Telnet	TCP 23/23	0.0.0.0

- 5) If it is a “well known” port highlight the Service under the **Name** section.
- 6) Click **Enable** at the properties section.
- 7) Type the IP address of computer that you want the port forwarded to in the **LAN (Server)** section.
- 8) Click **“Add”**.

Custom Ports

- 1) Log into the router by entering it’s IP address into a browser. The default IP address is <http://192.168.1.1>. The default username is admin with a password of admin.
- 2) Click on **“Cancel”** if the Setup Wizard comes up.
- 3) Click on **Access** on the left hand side.
- 4) Click on **Virtual Server**.



The screenshot shows the web interface for the Trendnet 54Mbps 802.11g Wireless Firewall Router TEW-432BRP. The page is titled "54Mbps 802.11g Wireless Firewall Router TEW-432BRP" and is accessed via "http://192.168.1.1/adv_virtual.html". The interface includes a navigation menu on the left with options like Main, Wireless, Status, Routing, Access, Management, Tools, and Wizard. The main content area shows the "Virtual Server" configuration page. At the top, there are tabs for Mac Filter, Protocol Filter, IP filter, Virtual Server, Special AP, DMZ, and Firewall Rule. Below the tabs, there are radio buttons for "Enable" (selected) and "Disabled". A form allows adding a new virtual server with fields for Name, Protocol (set to TCP), Private Port, Public Port, and LAN Server. Below the form are buttons for "add", "Update", "Delete", and "Clear". A table lists pre-defined virtual servers:


	Name	Protocol	LAN Server
<input type="checkbox"/>	Virtual Server FTP	TCP 21/21	0.0.0.0
<input type="checkbox"/>	Virtual Server HTTP	TCP 80/80	0.0.0.0
<input type="checkbox"/>	Virtual Server HTTPS	TCP 443/443	0.0.0.0
<input type="checkbox"/>	Virtual Server DNS	UDP 53/53	0.0.0.0
<input type="checkbox"/>	Virtual Server SMTP	TCP 25/25	0.0.0.0
<input type="checkbox"/>	Virtual Server POP3	TCP 110/110	0.0.0.0
<input type="checkbox"/>	Virtual Server Telnet	TCP 23/23	0.0.0.0

- 1) For Custom ports click **Enable**.
- 2) Type the name of the application.
- 3) Choose the protocol(s).
- 4) Enter in the ports. Public and Private Port should be the same.
- 5) Click "**Add**".

Q: How do I connect the TEW-432BRP using a DSL Connection?


First make sure you have the router physically connected properly. Connect the DSL modem via Ethernet to the **WAN** port of the TEW-432BRP. If you have any computers that need to be hard wired into the router you will connect them to one of the four **LAN** ports.

Make sure the connection from the modem to the router has a good link light. If it does not have a link light on or blinking swap out the cable you are using from the modem to the router or try a cross-over cable.




Step 1 Log into the router by entering its IP address into a browser. The default IP address is <http://192.168.1.1>. The default username is **admin** with a password of **admin**. They are case sensitive.

Step 2 Click **Main** on the left hand side then click on **WAN** at the top of the page.



Step 3 Change the **Connection Type** to **PPPoE**. Enter your **Username** and **Password** into the corresponding fields. Click **Apply**. After it has saved click on **Back**.

Step 4 Click **Status** on the left hand side then click **Device Information** at the top of the page. Check for an **IP Address** in the **WAN** section. If it is 0.0.0.0 click on **Connect**.



The screenshot shows the web interface of a TRENDnet 54Mbps 802.11g Wireless Firewall Router (TEW-432BRP). The browser window is Microsoft Internet Explorer, displaying the status page. The page title is "54Mbps 802.11g Wireless Firewall Router TEW-432BRP". The firmware version is 1.0.0, dated Thu, 28 Jul 2005. The interface is divided into sections: LAN, Wireless, and WAN. The WAN section is highlighted with a red box, and a mouse cursor is clicking the "Connect" button. The WAN section shows the following information:

WAN	
MAC Address	00-40-f4-dd-88-73
Connection	PPTP Disconnected <input type="button" value="Connect"/> <input type="button" value="Disconnect"/>
IP	66.52.25.101
Subnet Mask	255.0.0.0
Default Gateway	66.52.25.1
DNS	68.68.52.152

If you still do not pull an IP address after clicking connect please power cycle the modem and the router in the following fashion.

- Disconnect the power supply from the modem and the TEW-432BRP.
- Wait 30 seconds.
- Reconnect the modem's power supply and allow it to fully boot up.
- Reconnect the TEW-432BRP's power supply and allow it to fully boot up.

After this has been completed log back into the router and check the **Main>Device Information** section and check for an **IP Address** in the **WAN** section.

If it still does not have an IP address please verify your **Username** and **Password** with your Internet Service Provider.