

TEW-221PC

802.11b Wireless

CardBus PC Card

User Manual

REGULATORY STATEMENTS

FCC Certification

The United States Federal Communication Commission (FCC) and the Canadian Department of Communications have established certain rules governing the use of electronic equipment.

Part 15, Class B

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

?? Reorient or relocate the receiving antenna.

?? Increase the distance between the equipment and receiver.

?? Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

CAUTION:

- 1) To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons.
- 2) This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Table of Contents

INTRODUCTION	1
FEATURES.....	1
WIRELESS NETWORK OPTIONS.....	2
The Peer-to-Peer Network	2
The Access Point Network.....	3
LED INDICATORS.....	4
Link: Green (On/Off).....	4
Act: Orange (Blink).....	4
INSTALLING THE UTILITY.....	5
INSTALLING THE DEVICE	9
AUTOMATICALLY	9
MANUALLY.....	10
Under Windows 98.....	10
Under Windows ME	13
Under Windows 2000.....	15
Under Windows XP	18
VERIFY	20
NETWORK CONNECTION.....	21
CONFIGURING THE NETWORK PROTOCOLS FOR WINDOWS 98/ME.....	21

CONFIGURING THE NETWORK PROTOCOLS FOR WINDOWS 2000/XP	25
CONFIGURATION UTILITY	28
NETWORK STATUS ICON.....	29
The Status Icon	29
Link Info	30
Configuration	32
Encryption.....	34
Site Survey.....	37
Info	39
CONFIGURATION FOR WINDOWS XP	40
UNINSTALL PROCEDURE.....	48
UNINSTALL THE CONFIGURATION UTILITY.....	48
UNINSTALL THE DEVICE	49
SPECIFICATIONS	51

Introduction

The 802.11b Wireless 32bit TEW -221PC is a device that lets you connect your notebook to a wireless local area network (LAN). A wireless LAN is like a regular LAN, except that you can share information without looking for a place to plug in, and augment networks without installing or moving wires. Based on radio frequency (RF) technology, a wireless LAN transmits and receives data over the air, along with the guarantee to provide privacy and noninterference by the use of separate radio frequency.

The 802.11b Wireless 32bit TEW -221PC allows you to take full advantage of your notebook's mobility with access to real-time information and online services anytime and anywhere. Plus, with the network installation simplicity and flexibility, you can eliminate the need to pull cable through walls and ceilings and allow the network to go where wires cannot go. Exploring WWW and augmenting networks can't be done more easily.

Features


- ☞☞ Complies with IEEE 802.11b standard for 2.4GHz Wireless LAN
- ☞☞ Complies with PC Card standard
- ☞☞ Supports PC Card hot swap and true Plug & Play

- ✍ Works with all existing network infrastructure
- ✍ Complies with specific wireless products and services
- ✍ Capable of up to 128-Bit WEP Encryption
- ✍ Freedom to roam while staying connected
- ✍ 11 Mbps high-speed transfer rate
- ✍ Rich diagnostic LED indicators with Integrated Antenna
- ✍ Complies with Window 98/2000/ME/XP
- ✍ Lower power consumption
- ✍ Easy to install and configure


Wireless Network Options

The Peer-to-Peer Network

This network installation lets you set a small wireless workgroup easily and quickly. Equipped with wireless PC Cards or wireless PCI, you can share files and printers between each PC and laptop.




Or you can use one computer as an Internet Server to connect to a wired global network and share files and information with other PCs via a wireless LAN.



The Access Point Network

The network installation allows you to share files, printers, and Internet access much more conveniently. With wireless PC Cards, you can connect wireless LAN to a wired global network via an **Access Point**.



LED Indicators

Link: Green (On/Off)

Glow – linking to an Access Point or Peer-to-Peer mode.

Act: Orange (Blink)

Blink – Transmitting/receiving wireless data.

Installing the Utility


Note: Installing the Adapter's utility program before installing the device is highly recommended for saving time.

For Windows XP users:


There are two options for you to choose:

- ✎ Follow below instructions to install the utility.
- ✎ Skip this section. Go to **Installing the Device – Manually - Under Windows XP** section to install the device, and then you can use the built-in utility in Windows XP.


1. Insert the **Setup Utility CD-ROM** into the CD-ROM drive and double click on **Setup.exe** to install the **Wireless LAN Utility**.




2. When the Welcome screen appears, click **Next** to continue.




3. The **Choose Destination Location** screen will show you the default destination chosen by the utility. Click **Next** to continue.




4. Follow the instruction to select the program folder. Click **Next** to continue.




5. In **Start Copying Files**, click **Next** to continue.



6. In **Setup Status**, the InstallShield Wizard will begin copying the files.



7. After the **Wireless LAN Utility** has been successfully installed, select **Yes, I want to restart my computer now**, and then click **Finish** to restart.



Installing the Device

Automatically

If the Application setup in **Installing the Utility** section has been completed, follow the steps below to install the device.

1. Locate the CardBus slot of your system.
2. Align the Wireless PC Card toward the CardBus slot. Push evenly and steadily until it is seated.

After the device has been connected to your computer, Windows will detect the new hardware and then automatically copy all of the files needed for networking.

For Windows 98 users: As you perform the installation, have your Windows 98 CD-ROM at hand. You may be asked to insert the Windows 98 CD-ROM for the system to download a specific driver.

For Windows 2000 users: When **Digital Signature Not Found** screen appears, click **Yes** to continue.

For Windows XP users:

1. Select **Install from a list or specific location (Advanced)** and click **Next**.
2. Click **Continue Anyway**.
3. Click **Finish** to complete the installation.

Manually


If you want to install the device before installing the utility program, please follow the steps below.

1. Locate the CardBus slot of your system.
2. Align the Wireless PC Card toward the CardBus slot. Push evenly and steadily until it is seated.


After the device has been connected to your computer, Windows will detect the new hardware automatically.

Under Windows 98


1. In **Add New Hardware Wizard**, click **Next**.




2. Select **Search for the best driver for your device (Recommended)**. Click **Next**.




3. Insert the device driver CD-ROM into the CD-ROM drive. Select **CD-ROM** and **Specify a location:** and click **Browse** to provide the appropriate path (e.g. **D:\Win9xMe**). Click **Next**.



4. Click **Next**, Windows will copy all the necessary files to your system.
5. Insert **Windows 98** CD-ROM, and then click **OK**.




6. Click **Finish** to complete the installation.




7. When Windows prompts you to restart your computer, click **Yes**.

Under Windows ME


1. Select **Specify the location of the driver (Advanced)**, click **Next**.




2. Insert the device driver CD-ROM into the CD-ROM drive. Select **Search for the best driver for your device (Recommended)** and click **Browse** to provide the appropriate path (e.g. **D:\Win9xMe**). Click **Next**.



3. Click **Next**, Windows will copy all the necessary files to your system.



4. Click **Finish** to complete the installation.




5. When Windows prompts you to restart your computer, click **Yes**.

Under Windows 2000


1. In **Found New Hardware Wizard**, click **Next**.




2. In **Install Hardware Device Drivers**, select **Search for a suitable driver for my device (recommended)**, click **Next**.




3. Insert the device driver CD-ROM into the CD-ROM drive. Select **CD-ROM drivers** and **Specify a location**, click **Next**.




4. Click **Browse** to provide the appropriate path (e.g. **D:\Win2kXP**). Click **OK**.



5. Click **Next**, Windows will copy all the necessary files to your system.




6. In **Digital Signature Not Found** window, click **Yes** to continue.




7. Click **Finish** to complete the installation.
8. Restart your computer.

Under Windows XP


1. Once the device is well connected to your computer, Windows XP will automatically detect the new device. Select **Install from a list or specific location (Advanced)** and click **Next**.




2. Insert the **Setup Utility CD-ROM** into the CD-ROM drive. Select **Include this location in the search:** and click **Browse** to provide the appropriate path (e.g. **D:\Win2kXP**). Click **Next**.



3. Click **Continue Anyway** to proceed. Windows will copy all the necessary files to your system.




4. Click **Finish** to complete the installation.



Verify

To verify that the device exists in your computer and is enabled, go to **Start** ↗ **Settings** ↗ **Control Panel** ↗ **System** ↗ **Hardware**. Click the **Device Manager** tab. If the **802.11b Wireless CardBus PC Card** is found, it means that your device is properly installed and enabled.




Network Connection

Once the driver has been installed, you must make some changes to your network settings.

Configuring the Network Protocols for Windows 98/ME

1. Go to **Start** ↗ **Settings** ↗ **Control Panel** ↗ **Network**.
2. Make sure that you have all the following components installed.



↗ **802.11b Wireless CardBus PC Card**

↗ **IPX/SPX-compatible Protocol**

↗ **NetBEUI**


TCP/IP

If any components are missing, click on the **Add** button to add them in. Microsoft provides all the protocols and clients required and listed above.

5. After clicking **Add**, highlight the component you need, click **Add**.




6. Highlight **Microsoft**, and then double click on the item you want to add. Click **OK**.




7. For making your computer visible on the network, enable the **File and Printer Sharing**.


8. Click the **Identification** tab. Make up a name that is unique from the other computers' names on the network. Type the name of your workgroup, which should be the same name used by all of the other PCs on the network.



9. Click the **Access Control** tab. Make sure that "**Shared-level access control**" is selected. If connecting to a Netware server, share level can be set to "**User-level access control.**"



10. When finished, reboot your computer to activate the new device.



11. Once the computer has restarted and Windows has booted up, a **Logon** window will appear and require you to enter a username and password. Make up a username and password and click **OK**. Do not click the **Cancel** button, or you won't be able to log onto the network.
12. Double-click the **Network Neighborhood** icon on the windows desktop, and you should see the names of the other PCs on the network.


Configuring the Network Protocols for Windows 2000/XP


1. (For Windows 2000)

Go to **Start** ↗ **Settings** ↗ **Control Panel** ↗ **Network and Dial-up Connections** ↗ **Local Area Connection** ↗ **Properties**.

(For Windows XP)

Go to **Start** ↗ **Settings** ↗ **Control Panel** ↗ **Network and Internet Connections** ↗ **Network Connections** ↗ **Wireless Network Connection Enabled 802.11b Wireless CardBus PC Card** ↗ **Properties**.





2. Make sure that you have all the following components installed.



~~///~~ **Client for Microsoft Networks**

~~///~~ **NWLink NetBIOS**

~~///~~ **NWLink IPX/SPX/NetBIOS Compatible Transport Protocol**

~~///~~ **Internet Protocol (TCP/IP)**

3. If any components are missing, click on the **Install...** button to select the **Client/Service/Protocol** required. After selecting the component you need, click **Add...** to add it in.




4. For making your computer visible on the network, make sure you have installed **File and Printer Sharing for Microsoft Networks**.
5. When finished, you must restart your computer to complete installation.

Configuration Utility

After installing the Wireless PC Card's driver successfully, the **Network Status** icon will appear in the task bar. You can open it by double-clicking on this icon.






If the icon doesn't appear automatically, go to **Start** ↗ **Programs** ↗ **Wireless LAN Utility** ↗ **Wireless LAN Utility**, it will appear in the task bar.








Note: Except for the following configuration utility, using Windows to configure the wireless network settings in the Windows XP is recommended. (Please skip to the **Configuration for Windows XP** section)

Network Status Icon

The Status Icon


Icon	Link Status
	Access Point mode. (Please refer to below table for the exact link quality)
	Peer-to-Peer mode.
	No connection.

Icon	Signal Strength
	Excellent link quality.
	Good link quality.
	Poor link quality.
	Bad link quality.



Link Info

The **Link Info** tab will display the current status of the Wireless Network Adapter.




Item	Description
Status	It displays the information about the status of the communication (the BSSID of the Access Point to which the card is associated).
SSID	The SSID is the unique name shared among all points in your wireless network. The name must be identical for all devices and points attempting to connect to the same network. It shows the current SSID setting of the Wireless Network Adapter.
Tx Rate	It shows the current transfer rate. (1, 2, 5.5, 11Mbps or Auto)

Item	Description
Channel	It shows the selected channel that is currently used. (There are 14 channels available, depends on the country.)
Link Quality	It displays the link quality of the connection between the Wireless Network Adapter and the Access Point.
Signal Strength	It displays the signal strength of the connection between the Wireless Network Adapter and the Access Point.
Data Rate	It displays the current transmitting and receiving rate.

Configuration

You can change advanced configuration settings, such as the **SSID**, **Operation Mode**, **Tx Rate** and **Preamble Type**.







Item	Description
SSID	SSID is the unique name shared among all points in your wireless network. It must be identical for all points in the network. It is case-sensitive and must not exceed 32 characters. Make sure that all points in the network are set to the same SSID.
Operating Mode	It displays the current operating mode. (Access Point or Peer-to -Peer).
Channel	Select the appropriate channel from the list provided to correspond with your network settings. All devices in the

Item	Description
	wireless LAN must be configured to share the same radio channel in order to work correctly. (There are 14 channels available, depends on the country.)
Tx Rate	Select (1, 2, 5.5, 11Mbps or Auto) from the drop-down list to change the current transfer rate
<p data-bbox="107 485 273 521">Preamble</p> <p data-bbox="107 706 239 741">✎ Auto</p> <p data-bbox="107 879 273 956">✎ Long Preamble</p> <p data-bbox="107 1010 273 1087">✎ Short Preamble</p>	<p data-bbox="314 485 939 688">A preamble is a signal used in wireless environment to synchronize the transmitting timing including Synchronization and Start frame delimiter.</p> <p data-bbox="314 706 939 867">Select Auto for the Network adapter to select the Preamble type automatically depending on the Access Point Preamble type.</p> <p data-bbox="314 879 939 998">In a "noisy" network environment, the Preamble Type should be set to Long Preamble.</p> <p data-bbox="314 1010 939 1213">The Short Preamble is intended for applications where minimum overhead and maximum performance is desired. In a "noisy" network environment, the performance would be decreased.</p>
Radio	Select On/Off from the drop-down list to enable/disable the Radio Module function of the Wireless Network Adapter.

Encryption

WEP (Wired Equivalent Privacy) encryption can be used to ensure the security of your wireless network.



Item	Description
Data Encryption	<p>WEP is a data privacy mechanism based on a 64 Bit/128 Bit shared key algorithm.</p> <p>Check this box to enable WEP encryption.</p>
Auth. Mode Open Authentication Shared Authentication Auto	<p>The authentication mode defines configuration options for the sharing of wireless networks to verify identity and access privileges of roaming wireless network cards.</p> <p>You may choose between Open Authentication, Shared Authentication, and Auto.</p> <p>If the Access Point is using "Open Authentication", then the wireless adapter will need to be set to the same authentication mode.</p> <p>Shared Authentication is when both the sender and the recipient share a secret key.</p> <p>Select Auto for the network adapter to select the Authentication mode automatically depending on the Access Point Authentication mode.</p>
Key Length	64 Bit or 128 Bit.
WEP Key  1  2  3  4	<p>This setting is the configuration key used in accessing the wireless network via WEP encryption.</p> <p>Fill in the appropriate value/phrase.</p>
Apply	Click Apply to save the changes.


Cancel

Click **Cancel** to exit the application.



Note: You must use the same value/phrase or WEP key settings for all wireless computers in order for the wireless network to function well

Site Survey

The **Site Survey** tab shows all the available Access Points and their features.



Item	Description
SSID	It displays the current SSID setting of the Wireless Network Adapter.
WEP	It displays the status of WEP Encryption.
Channel	It displays the selected channel that is currently used.
Signal	It displays the signal strength of the connection between the Wireless Network Adapter and the Access Point.
BSSID /IBSSID	A set of wireless stations is referred to as a Basic Service Set (BSS). Computers in a BSS must be configured with the same BSS ID.

Item	Description
Type	It displays the type of Basic Service Set. ( Access Point or  Peer-to-Peer)
Re-Scan	Search for all available networks. By clicking on the button, the device will start to rescan and list all available sites.
Connect	Select one from the list to connect.

Info


You can view basic information about the Utility like the **Driver** and **Utility** Version.




Configuration for Windows XP


1. Go to **Start** ↗ **Control Panel** ↗ **Network Connections**.
2. In **Network Connections** window, right-click the **Wireless Network Connections** icon, and select **Properties**.

Note: Double-click the **Wireless Network Connection** icon and you can see the status of the wireless PC Card as described below.




3. In **Wireless Network Connection Properties** window, select the **General** tab. Click **Configure** to enable Windows configuration.



Property	Description
Antenna	(Diversity, Antenna A or Antenna B): These settings determine which antenna will be used to transmit or receive.
Channel	Select the appropriate channel from the list provided to correspond with your network settings. All devices in the wireless LAN must be configured to share the same radio channel in order to work correctly. (There are 14 channels available, depends on the country.)
Data Rate	Select (1, 2, 5.5, 11Mbps or Auto) from the drop-down list to change the transfer rate.
Network Type	Select the appropriate Network Type from 802.11 AdHoc Mode (Active), 802.11 AdHoc Mode (Passive) or Infrastructure. In AdHoc mode , Active mode is recommended since it can generate/pass beacon packet automatically.
Preamble	A preamble is a signal used in wireless environment to synchronize the transmitting timing including Synchronization and Start frame delimiter.
 Auto	Select Auto for the Network adapter to select the Preamble type automatically depending on the Access Point Preamble type.

☞ Long Preamble	In a "noisy" network environment, the Preamble Type should be set to Long Preamble .
☞ Short Preamble	The Short Preamble is intended for applications where minimum overhead and maximum performance is desired. In a "noisy" network environment, the performance would be decreased.
RTS Threshold	This value should remain at its default setting of 2347 . Should you encounter inconsistent data flow, only minor modifications of this value are recommended.
Select Sharedkey Index	Select from 1, 2, 3, 4 or No selection .
Sharekey1 Sharekey2 Sharekey3 Sharekey4	This setting is the configuration key used in accessing the wireless network via WEP encryption. Fill in the appropriate value/phrase.
SSID	SSID is the unique name shared among all points in your wireless network. It must be identical for all points in the network. It is case-sensitive and must not exceed 32 characters. Make sure that all points in the network are set to the same SSID.
WEP	WEP is a data privacy mechanism based on a 64 Bit/128 Bit shared key algorithm. Select WEP key 128bit or WEP key 64bit to enable WEP encryption.


4. In **Wireless Network Connection Properties** window, select the **Wireless Networks** tab.



Use Windows to configure...

Check the box to enable windows configuration.

Note: Once you enable windows configuration, then the Network Status in the taskbar will disappear. You cannot use this utility to configure the wireless settings.



Note2: If you want to use the utility in Configuration Utility section to configure the wireless settings. Make sure the check box is **not** enabled then click the Network Status icon in the taskbar.




Available networks

Displays all available networks.

Configure

Click the button to set up a new network or WEP configuration as illustrated as below.



Refresh

Click the button to refresh and search for all available networks.

Preferred networks

From available network(s) listed above, you can set preferences in an order that you can arrange.

The marked one is the currently used network.

Move up

Move the selected network forward one position.

Move down

Move the selected network back one position

Add...

Click the button and the **Wireless Network Properties** window will appear. In the **Network name** field, enter your desired network name listed in the above **Available networks** box, and click **OK**.

Note: The new settings will be active only after you click on **OK** in the Wireless Network Connection Properties window.

Remove

Highlight the unwanted network listed in the **Preferred networks** box, and click the button to remove it.

Properties




Highlight the network listed in the above **Preferred networks** box, and click the button to display its properties.



Once network configuration is done, make sure to click **OK**. The new parameters will be saved and active only after doing so.

Uninstall Procedure


Note: In case you need to uninstall the Utility or device, please refer to below section.

Uninstall the Configuration Utility


1. Go to **Start**  **Programs**  **802.11 Wireless LAN**  **Uninstall Configuration & Monitor Utility.**



2. Click **OK** to continue.





3. Click **Finish** to complete the uninstalled procedure.




Uninstall the device

1. Right-click **My Computer ? Properties ? Hardware ? Device Manager**.
2. Select or right-click **802.11b Wireless CardBus PC Card** then click **Remove**. Click **OK**.



3. The system will prompt you to restart your computer. Click **Yes**.



Specifications

Standards	IEEE 802.11b,Wi-Fi compliant
Host Interface	32-bit CardBus
Antenna	Built-in Diversity Antenna
Physical Specifications	Weight: 40 g Dimension: 119(L) x 53.94 (W) x 6.88(H) mm (4.7"x2.12"x0.27")
LED Indicators	LINK: Green (ON) ACT: Orange (Blink)
Power Requirement	Operating Voltage: 3.3V TX consumption: 450mA (Max) RX consumption: 300mA (Max)
Operating Frequency Range	2.412GHz-2.4835GHz
Number of Selectable Channels	USA, Canada: 11 channels Europe: 13 channels Japan: 14 channels
Modulation Technique	Direct Sequence Spread Spectrum (CCK, DQPSK, DBPSK)
Security	0/64/128 bit WEP
Spreading	11 chip Barker sequence
Bit Error rate	Better than 10^{-5}
Media Access Protocol	CSMA/CA (Collision Avoidance) with ACK
Supported OS	Windows 98/ME/2000/XP
EMC Certification	FCC Part 15 in US EN300328 and EN300826 (EN301489-17) in Europe Japan-Telec in Japan

Environment Specifications	Operating Temperature: 0~65? (32~149°F) ambient temperature Storage Temperature: -20~75? (-4~167°F) ambient temperature Operating humidity: 95% maximum (non-condensing) Storage humidity: 95% maximum (non-condensing)
-----------------------------------	--