User's Guide

TRENDNET



Outdoor 3 MP Full HD 1080p PoE IR Network Camera

TV-IP312PI

Contents

rodu	uct Overview	. 4	
Fea	Features		
Hai	Hardware		
A	Adjustable Bracket	. 4	
F	PoE	. 4	
F	Power Port	. 4	
(Outdoor Ready	. 4	
9	Sun Visor	. 4	
Per	formance	. 4	
3	3 Megapixel	. 4	
ſ	Night Vision	. 4	
9	Smart IR	. 4	
[Digital Zoom	. 4	
- 1	Pv6	. 4	
A	Advanced Playback	. 5	
[D-WDR	. 5	
9	Storage	. 5	
F	Free Apps	. 5	
(Complimentary Software	. 5	
Pac	ckage Contents	. 5	
Car	mera Overview	. 6	
Wa	arnings	. 6	
Cau	utions	. 7	

Installation Procedure	7
Plan for installation location	7
Viewing angle	7
Weather Conditions	8
Hardware Installation	8
Cabling	8
Waterproof cap	8
Mount your camera	9
Setup Your Camera with CD	10
Access your Camera with the Web Browser	12
Logging-in to the Camera for the First Time (Windows)	12
Logging-in to the Camera for the First Time (OS X)	14
Live View	19
Playback	20
Search for video recordings	20
Time Line	20
Playback	21
Slice images from video playback	21
Download sections of video	22
Download snapshots	22
Log	23
Search for logs	23
System Information	24
System Configuration	

	Device Settings	26
	User Accounts	27
	Time Settings	27
	Daylight Savings	28
	Live View Settings	29
	Maintenance	30
V	etwork Settings	31
	TCP/IP	31
	Port	32
	DDNS	32
	PPPoE	33
	SNMP	33
	802.1X	35
	IP Address Filter	35
	Quality of Service (QoS)	36
	UPnP	36
۷i	deo Settings	37
	Video Format	37
	Display Settings	38
	On Screen Display Settings	40
	Text Overlay	41
	Privacy Mask	41
	Video Recording	42
Ξ١	ventsvents	43
	Motion Detection	43

	Video Tamper	. 45
	Exception	46
	Snapshot	47
	Email	48
N	etwork Storage	49
	Network Storage	49
	Storage Management	50
	FTP Server	. 51
Re	egulations	. 52
	Federal Communication Commission Interference Statement	. 52
	RoHS	. 52
	Europe – EU Declaration of Conformity	53
Li	mited Warranty	. 54

Product Overview



TV-IP312PI

Features

TRENDnet's Outdoor 3 MP Full HD 1080p PoE IR Network Camera, model TV-IP312PI, offers night vision up to 50 meters (164 ft.), an IP66 weather rating, and an integrated mounting bracket. Ultra energy efficient advanced infrared creates a more balanced night vision illumination field and reduces close object overexposure. Record 3 Megapixel HD video (2048 x 1536) at 20 fps in a space saving H.264 compression format. Manage up to 32 TRENDnet cameras with included complimentary software and mobile apps.

Hardware

Adjustable Bracket

Fully adjustable integrated mounting bracket provides installation flexibility

PoE

Save installation costs with Power over Ethernet (PoE)

Power Port

Optional power port for non-PoE installation

Outdoor Ready

Outdoor IP66 weather rated

Sun Visor

Sun visor increases image quality throughout the day

Performance

3 Megapixel

Record 2048 x 1538 pixel video at 15 fps in H.264 compression

Night Vision

Night vision up to 30 meters (100 ft.) in complete darkness

Smart IR

Dynamic IR adjustment optimizes night visibility

Digital Zoom

Digitally zoom anywhere within the viewing field

IPv6

IPv6 support

Advanced Playback

Advanced in-camera archived video review functionality

D-WDR

Digital Wide Dynamic Range improves video quality in high contrast lighting environments

Storage

Samba video support with notification if storage drive is full

Free Apps

See live video on a mobile device with free Apple® and Android™ apps


Complimentary Software

Complimentary pro-grade software to manage up to 32 TRENDnet cameras

Package Contents

TV-IP312PI package includes:

- TV-IP312PI
- Quick Installation Guide
- CD-ROM (Utility, Software & User's guide)
- Camera Mounting hardware
 (Drill template, mounting screws, waterproof cap, torx screw driver)
- (Optional power adapter not included)



If any package content is missing or damaged, please contact the retail store, online retailer, or reseller/distributor from which the product was purchased.

Camera Overview



Optional Power	This model is designed to power by PoE. For non-PoE user,		
Connector	please connects the power adapter (12VDC1A sold separately) to camera.		
Ethernet/PoE	Plug the network cable to connect to supply power to the		
Port	camera if using non-PoE connection.		
Mounting	Adjust the screws to fit the mounting position		
Hardware			
IP66 Housing	Housing is rated with IP66.		
IR Sensor	Detect the light source.		
IR LEDs	The IR LEDs will be on when the sensor detect low light		
	source.		
Adjustable Sun Visor	Adjustable sun visor to prevent direct sun to the camera.		

Warnings

Serious injury or death may be caused if any of these warnings are neglected. Follow these safety guards to prevent serious injury or death.

- If using the power adapter, please choose the power adapter that meets the safety extra low voltage (SELV) standard or IEC60950-1 and Limited Power Source standard.
- If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the camera yourself. Disassembling the product will void the warranty and may cause harm or injury.
- To reduce the risk of fire or electrical shock, do not expose this product to rain or water.
- The installation should be done by a qualified service person and should conform to all construction and electric regulations and other local codes.

TRENDnet User's Guide TV-IP312PI

Cautions

Injury or equipment damage may be caused if any of these cautions are neglected. Follow these precautions to prevent potential injury or material damage.

- Make sure the power supply voltage is correct before using the Camera.
- Do not drop the camera or subject to physical shock.
- Do not touch sensor modules with fingers. If cleaning is necessary, use a clean cloth with a bit of ethanol and wipe it gently. If the camera will not be used for an extended period of time, put on the lens cap to protect the sensor from dirt.
- Do not aim the camera lens at the strong light such as the Sun or an incandescent lamp. Strong light can damage the camera sensor.
- The sensor may be burned out by a laser beam, so when any laser equipment is being used, make sure that the surface of the sensor will not be exposed to the laser beam.
- Do not place the camera in extremely hot, cold temperatures (the operating temperature should be between -10°C to 60°C), dusty or damp environment, and do not expose it to high electromagnetic radiation.
- To avoid heat accumulation, good ventilation is required for a proper operating environment.
- Keep out of water and any liquid.
- While shipping, the camera should be packed in its original packing.

Installation Procedure

There are number of factors involved in a successful camera installation. Follow the suggested installation steps and go through the check lists. This guide will help you make your camera installation smoothly and easily.

Plan for installation location

Viewing angle

The TV-IP312PI is a bullet camera with a focused viewing angle (70° horizontal) that provides non-distorted and detailed images. Choose the location where has good angle to shoot the image you expect to see. The motion detection area should also be considered when installing the camera.

Weather Conditions

The TV-IP312PI is a small bullet camera, which fits most installations indoor and outdoor. The camera can work under a wide range of weather conditions. For severe weather conditions, a camera housing with temperature and moisture control is recommended. Using the camera in milder weather conditions will help extend the camera's product life and preserve the quality of the video image.

- Moisture: Avoid damp or moist environments whenever you can. The TV-IP312PI is an IP66 grade water proof camera, and it will work in moist environments. However, rain may affect the picture quality, especially at night, water may reflect the light from the infra-red illumination and degrade picture quality.
- Temperature: TV-IP312PI works within a specified temperature range.
 Areas with severe temperatures should be avoided when installing the camera. It's recommended that you use an enclosure with a heater and blower if you plan on using this camera outside of the specified temperature range.
- **Sunlight:** Avoid direct sun light exposure. Direct sun light will damage the image sensor. If sunlight is necessary for your viewing purposes, provide protection for the image sensor.
- **Lighting:** Consider installing your camera faces the same direction of the light sources. Shooting images with top-down position outdoor or next to the existing light source are good choices. Avoid the light source if it creates a shade that darkens the viewing area.


Hardware Installation

Cabling

It's recommended that the wiring the cable in your home or office by a professional. If you already have the cable deployed, make sure the cable and the connectors meet the category 5 Ethernet cable standards. At least 2 pairs of twisted lines are required for power and data. Poor cable quality may cause unexpected problems. Testing your cable or running a new cable is suggested for new camera installation.


Waterproof cap

The TV-IP312PI itself is IP66 grade water and dust proof. There is a set of network cable water proof caps that comes with the package as well. Run your cable going through the accessories, and then crimp the cable with an RJ45 module. Plug in the network cable and then tighten the waterproof cap to prevent water running into camera through the cable.




Mount your camera

1. Loosen the locking bolts and manually position the camera as desired.




2. Place the provided drill template on the wall or ceiling.



- Drill holes for the provided screw anchors at each marked position on the template. Make sure the drill bit matches the size of the provided screw anchors.
- 4. If the camera wire will be installed through the based plate of the unit, skip to step 6. If the wiring will be routed though the wall, drill a hole for the cable.
- 5. Pass the camera's cables through the hole.
- 6. Connect the network cable to the camera.
- 7. Insert the provided screw anchors into the pilot holes.

8. Align the mounting bracket with the screw anchors, and then use the provided screws to secure the camera to the mounting surface.



- 9. Power up the camera by connecting the other end of the cable to a PoE switch or injector on your network.
- 10. Loosen the screws and rotate the collar to final angle, then the screws.




Setup Your Camera with CD


1. Insert the Installation CD-ROM into your computer's CD-ROM drive to initiate the Auto-Run program. Choose your preferred language and then click the **Install Camera Utility**.



2. Install the Camera Utility as instructed




3. Last, click Next to finish the installation.



4. This will also require you to Install WinPcap program if you don't have this installed before, please follow the on screen Instructions to Install It.




5. Restart the computer after the Installation.



6. After the computer has restarted, double click on the Camera Utility icon to launch the program.



7. Find the camera you would like to access and configure then double click on the IP address.




8. Continue to the next section **Access your Camera with the Web Browser** for detail configurations of the camera.


Access your Camera with the Web Browser

Logging-in to the Camera for the First Time (Windows)


1. Find the camera from the Utility and double click on the IP address to open the browser.



2. Activate the **admin** User Account by entering your desired password, and then click **OK**.




3. The camera management page will detect if you installed the camera video streaming plug-in or not. Click the link to download the plug-in from the camera.




4. Download the plug-in to your computer and then and close your browser. Launch the plug-in installation to install the plug-in.




5. Permission request may show up depends on the Internet security settings on your computer. Click **Yes** to install the plug- in.



6. Click **Next** to install the plug-in.




7. Click **Finish** to finish the installation.



8. Open the browser and login again. Enter the user name **admin** and new password again to start secured session.




9. Refresh the browser and the Live View page will show up and begin streaming video.




Logging-in to the Camera for the First Time (OS X)

1. Open the web browser on your computer. In the address bar, enter the default IP address of the camera 192.168.10.30. If the camera is connected to a router/network, please use the Windows Camera Utility to find the exact IP address.




2. Activate the **admin** User Account by entering your desired password, and then click **OK**.



3. The camera management page will detect if you installed the camera video streaming plug-in or not. Click the link to download the plug-in from the TV-IP312PI camera.


Note: Internet connection is required to download the plug-in. If you do not have Internet access, you can find the plug-in on the CD comes with the package under /Mac folder.



4. Quit your browser completely by **command-Click** on the browser icon and then click **Quit** before installing the plug-in.



5. Go to the **Finder** and navigate to the **Download** folder. **Command-Click** the **WebComponents.pkg** and then click **Open**. (If you are install the plugin from the CD, just browse to /Mac folder and double click the **WebComponents.pkg** file.)



6. Click **Open** to start installation.




7. Click **Continue** to install the plug-in.



8. Select a destination to install the plug-in. Then click **Continue**.




9. Use the default location and click Install.




10. Enter your password and click Install Software



11. Installation will process automatically.



12. Click **Close** to exit the installation.



13. Open the browser and login again with the default IP 192.168.10.30 or the IP that was dynamically assigned by your router.



14. Enter your user name and password, then click Login



15. Click **Trust** (You'll have to do this again when your camera changes to a new IP address.)



16. The Live View page shows up and the video starts to stream.



Live View

After you log-in into the camera management page, you'll see the Live View page.



Click this icon to take a video snapshot.

🤐 Recording


Click once to start recording. Click it again to stop recording. The status bar will indicate if it is in recording state or not.

Q Zoom

Click once to enable zoom. When enabled, click and drag the area on the picture to zoom in. Right click to resume 100% zoom. Click the icon again to disable zoom. The zoom function works in full screen mode as well.



TV-IP312PI has two video streams: H.264 and MJPEG. Switch to view the different video streams by clicking this icon.



Full Screen Mode

Click the picture to view in full screen mode. Double click again or press escape key on your keyboard to exit full screen mode.

Status Bar

The status bar shows the status you are at, including enabled the zoom, recording video, and successfully taking a snapshot.


Where can I find saved files?

Videos and snapshots captured from Live View will save to your computer. See **Live View Settings** on page 29 for details.

Playback


You can playback the video recording on the network storage and download the video clip and snapshots to your local computer. (See

Network Storage on page 48 to setup the storage.)



Search for video recordings

Click the date selection, and then choose a date as the date range of searching. Click **Search** to start searching.



Time Line

There is a play back head in the center of the time line represented in a yellow vertical line. To look for a specific video recording, move the time line by clicking and dragging it. If the recording is short, zoom in by clicking button. Click to zoom out the time scale. If you know the exact time of the day you are looking for, click then enter the time you want to playback.

Different types of recordings are identified differently. The scheduled recordings are marked in blue, and the recordings triggered by motion detection are marked in red.



then click to confirm selection and then click **X** to close this dialog box.

Playback

Use playback controls to play back the video recording.





^{*} Note: There are 5 steps of playback speed you can choose from: 1/4, 1/2, 1, 2, and 4 times of original speed.

Slice images from video playback

You can take snapshots from playback video or make new video clips from the video you are playing back.



Click this button to enable zoom. Then click and drag on the video to define the area you want to zoom in. Click again to get back to 100% zoom.

Double click to show video in full screen and press ESC on keyboard to exit full screen mode.

Click this button to disable zoom.

Click this button to take a snapshot of current playback.

Click this button to start clipping a video from playback.

Click this button to stop clipping a video from playback.

Where can I find saved files?


Videos and snapshots captured from Playback will be saved to your computer. See **Live View Settings** on page 29 for details.

Download sections of video

To save complete video sections or snapshots, you can download the files directly.




Click button to download video sections.



Check the time of the recording, select the videos you want to download, and then click **Download**.

Download snapshots

Click ____ button to list snapshots to download



Schedule Motion

Select the type of event that triggered the snapshots. Choose the Start Time and End Time. Then, click **Search** to find the snapshot list. Check the time of the snapshot,

and then select the snapshots you want to download, then click **Download**.


Where can I find saved files?

Videos and snapshots captured from Playback will be saved to your computer. See **Live View Settings** on page 29 for details.

<u>Log</u>

The log of the TV-IP312PI will be saved on the network storage. You can search the relevant records and save to your local computer. (See

Network Storage on page 48 to setup the storage.)



Search for logs

Click the type of log and then the Start Time and End Time. Click **Search** to start searching.

Total 129 Items First Page Prev Page 1/2 Next Page Last Page


Click **First Page**, **Prev Page**, **Next Page**, and **Last Page** to show the logs. Click **Save Log** to save the logs to your computer.

Where can I find saved files?

Videos and snapshots captured from Playback will be saved to your computer. See **Live View Settings** on page 29 for details.

System Information

System Information page shows the TV-IP312Pl's basic information. Click System then click System Info to show the page.



Basic Information		
Device Name:	Human readable device name for easy	
	identification.	
Firmware Version:	Firmware version	
MAC Address:	The MAC address of Ethernet Interface	
System Time:	The system time setup in the camera. Keeping this time correct is important for recording, scheduled control and logging accurately.	
Network Information		
IP Address:	IP address of the TV-IP312PI	
Subnet Mask:	Network range of IP address	

TRENDnet User's Guide TV-IP312PI

Default Gateway:	The default route going from the TV-IP312PI
-------------------------	---

subnet.

Primary DNS: Primary DNS server address
Secondary DNS: Secondary DNS server address

TRENDnet User's Guide TV-IP312PI

System Configuration

Device Settings

Setup your camera name and location for easy identification. This camera name will also be recognized by other network camera software as the name of this camera. OSD, On Screen Display, camera name is referring to this setting as well.



Names

Camera Name: Name of the camera. The camera name setup here can be discovered by other network camera software and OSD, On Screen Display. The default camera name is the model number: TV-IP312PI

Location: Label where you installed this camera for reference

Authentication

RTSP: TV-IP312PI's video stream can be accessed with RTSP, Real Time Streaming Protocol. Only the administrator and users can view this video stream Un-checking this box will allow everyone access to this video stream without authentication. Default: Checked.

HTTP: TV-IP312PI can be accessed via password protected web management interface. Un-checking this box will allow anyone to access this camera and change its settings.

Service

Enable TV-IP312PI embedded SSH service for multiple camera **SSH:** control for system developer. Default: disabled.

User Accounts


You can setup up to 16 user accounts to access the camera's video stream with a web browser or real time video stream (RTSP). Only one administrator account can be setup to configure the TV-IP312PI and cannot be deleted.



User Accounts

Add: Click Add button to add one user account


Modify: To change a user's name and password, highlight the user by clicking on it. Then, click **Modify** button. You can change the user's name and password. You can also change the administrator's password here. But, the administrator's name is fixed, you cannot change that.



Click **OK** to save the changes.

Time Settings

The accuracy of the system clock is important for scheduling and accurate logging. You can synchronize the system time with your computer, or automatically check the time accuracy with a network time server (NTP server).



Automatic Update


NTP Specify a time server (NTP server) to synchronize with.

Server: (e.g. pool.ntp.org)

Interval: The time interval that the TV-IP312PI will synchronize the time

with NTP server. Default: 1440 minutes (24 hours)

TRENDnet User's Guide TV-IP312PI



Manual Time Sync

Device Time: The system time of this camera.

Set Time: Click the calendar icon and manually select the date.

Check the $\boldsymbol{Sync.}$ with $\boldsymbol{computer\ time}$ to copy the time

from your computer.

Click **Save** to save the changes

Daylight Savings

Setup daylight savings.




Automatic Update Enable DST: Check this box if your time zone has daylight savings. Start Time: Enter the date that daylight savings starts End Time: Enter the date that daylight savings ends DST Bias Enter how much time the daylight saving adjusted by daylight savings.

TRENDnet User's Guide TV-IP312PI

J. Ett. Court

Live View Settings

Setup the live view video quality, file size and file saving directories.



Live View Parameters

Live View Configure the buffer size for live view video stream. With Buffer: low buffer size setting, you can get real-time video stream, but the video may be stop and go if the network is congested. With high buffer setting, you can have smooth video streaming, but the video is delayed from the time happening. Medium size can have moderate video stream smoothness and time delay.

Record File Settings			
Record file size:	This size of live view video recording. You can choose 256MB, 512MB, or 1GB a file. Smaller file size is good for many short recordings.		
Save record files to:	By default, files will be saved under the folder with your user name, under the subdirectory TRENDnet/RecordFiles. Click Browse and then choose a new destination if you want to save the file somewhere else.		
Save downloaded files to:	By default, files will be saved under the folder with your user name, under the subdirectory TRENDnet/DownloadFiles. Click Browse and then choose a new destination if you want to save the file somewhere else.		


Picture and Clip Settings				
Save snapshots	By default, files will be saved under the folder with			
in	your user name, under the subdirectory			
live view to:	TRENDnet/SnapshotFiles. Click Browse and then			
	choose a new destination if you want to save the file			
	somewhere else.			
Save snapshots By default, files will be saved under the folder				
when playback	your user name, under the subdirectory			
to:	TRENDnet/PlaybackPics. Click Browse and then			
	choose a new destination if you want to save the file			
	somewhere else.			
Save clips to:	By default, files will be saved under the folder with			
	your user name, under the subdirectory			
	TRENDnet/PlaybackFiles. Click Browse and then			

choose a new destination if you want to save the file somewhere else.

TRENDnet User's Guide TV-IP312PI

Maintenance

You can restart, load camera settings and upgrade the camera firmware on this page.



Reboot

Reboot: Click this button to reboot this camera.

Reset

Reset: Reset all camera parameters, except the IP parameters

and user information.

Default: Load complete factory default to the camera.

Import Config. File

Config File: To load previously saved settings, click **Browse** to find the

configuration file and then click Import.

Status: Shows the status in loading configuration file.

Export Config. File

Export: Click Export to download configuration file. The file will

be downloaded to the Download folder by default.

Remote Upgrade

Firmware: Click Browse to find the latest firmware and then click

Upgrade.

Status: Shows the status in firmware upgrade.

TRENDnet may periodically release firmware upgrades that might add features or fix problems associated with your TRENDnet model and version. To find out if there is a firmware upgrade available for your device, please check your TRENDnet model and version using the link.


http://www.trendnet.com/downloads/

- 1. If a firmware upgrade is available, download the firmware to your computer.
- 2. Unzip the file to a folder on your computer.
- 3. Read the firmware upgrade instruction for specific version update information.
- 4. Log into the TV-IP312PI.
- 5. Getting to this Maintenance page to upgrade firmware.

Network Settings

TCP/IP

Setup your basic IPv4 and IPv6 network settings on this page.




Network Interface	
MAC Address:	Click this button to reboot this camera.
Duplex and Speed:	Choose one of the Ethernet duplex and speed to match your network. Default: auto.
MTU:	Maximum transmission unit. The maximum field size in the Ethernet packet.
Primary DNS:	Enter your first IPv4 or IPv6 DNS server address
Secondary DNS:	Enter your second IPv4 or IPv6 DNS server address
IPv4	
DHCP:	Check this box if the IP address is assigned by DHCP server.
IPv4 Address:	The IPv4 dynamic or static address
Subnet Mask:	Network range of the subnet
Default Gateway:	The default route going further from TV-IP312PI IPv4 subnet
IPv6	
IPv6 Mode:	Choose Manual, DHCP, or Route Advertisement. Click View Route Advertisement to find a route
	advertisement.
IPv6 Address:	advertisement. IPv6 address of TV-IP312PI

Default The default route going further from TV-IP312PI IPv6

Gateway: subnet

Port

You can change the service port numbers of TV-IP312PI and enable/disable RTSP or HTTPS services.





Port Numbers HTTP Port: The default web access port. You can change the port number. However, you cannot disable the web service. The default port number is 80. RTSP Port: The Real-Time Streaming Protocol port for video streaming. You can change the port number or disable the service by uncheck the box. The default port number is 554. HTTPS Port: The secured web service port. You can change the port number, or you can disable the service by uncheck the box. The default port number is 443.

Click **Save** to save the changes

DDNS

Dynamic Domain Name Service, DDNS, allows you to find your camera from the Internet with an easy to remember domain name.






Click **Save** to save the changes

PPPoE

Setup PPPoE (ADSL) connection to connect your camera with your ISP, Internet Service Provider.



PPPOE (ADSL) Enable PPPOE: Check this box to enable PPPoE connection. Dynamic IP: The IP address assigned by ISP User Name: Enter the account name. Password: Enter the password. Confirm: Enter the password again.

Click **Save** to save the changes

SNMP

SNMP Settings allows you to assign the contact details, location, community name and trap settings of SNMP. This is a networking management protocol used to monitor network-attached devices. SNMP allows messages (called protocol data units) to be sent to various parts of a network. Upon receiving these messages, SNMP compatible devices (called agents) return data stored in their Management Information Bases.



SNMP V1/V2	
Enable SNMPv1:	Check this box to enable SNMP v1 management.
Enable SNMPv2c:	Check this box to enable SNMP v2c management.
Read SNMP	Specify the password to access the SNMP
Community:	community for read only access.
Write SNMP	Specify the password for access to the SNMP
Community:	community with read/write access.
Trap Address:	Specify the IP address for the SNMP trap
	community.
Trap Port:	Specify the port number for the SNMP trap
	community.
Trap Community:	Specify the name of SNMP trap community.

SN	ΝЛ	D 1	12
SIN	IVI		v 3

Enable SNMPv3: Check this box to enable SNMP v3 management.

Read User Name: SNMP v3 member user name.

Security Level: Choose one of the security levels.

Authentication and Privacy

Authentication only Privacy only

Authentication Choose the authentication method to verify the

Algorithm: source of information: MD5 or SHA.

Authentication Specify the authentication password between 8 to

Password: 32 letters.

Private-key Choose the privacy key to encrypt SNMP messages:

Algorithm: DES or AES.

Private-key Specify the privacy key between 8 to 32 letters.

Password:

Write User SNMP v3 manager user name.

Name:

Security Level: Choose one of the security levels.

Authentication and Privacy
Authentication only

Privacy only

Authentication Choose the authentication method to verify the

Algorithm: source of information: MD5 or SHA.

Authentication Specify the authentication password between 8 to 32

Password: letters.

Private-key Choose the privacy key to encrypt SNMP messages:

Algorithm: DES or AES.

Private-key Specify the privacy key between 8 to 32 letters.

Password:

SNMP Other Settings

SNMP Port: SNMP service port number.

TRENDnet User's Guide TV-IP312PI

802.1X

Setup 802.1X for remote authentication service.



802.1X Authentication

Enable IEEE Check this box to enable 802.1X authentication

802.1X: service.

EAPOL version: Extensible Authentication Protocol (EAP) over LAN

(EAPoL). Choose version 1 or 2. This version number

has to match to your 802.1X service EAPOL version.

User Name: Enter the account name.

Password: Enter the password.

Confirm: Enter the password again.

Click **Save** to save the changes

IP Address Filter

Set up a list of clients allow only the clients on the list to access this camera or to reject clients on the list from access this camera.





IP Address Filter	
	Check this box to enable IP address filtering service.
Address Filter:	
IP Address Filter	Choose Deny to ban the listed IP addresses or
Type:	Allowed to allow listed host to access this camera.
Add:	Click Add to add a user account
Modify:	To modify an entry on the list, highlight the entry by
	clicking on it. Then, click the Modify button.
	Modify IP Address
	IP Address 10.10.10.10 X
	OK Cancel
	Enter the IP address then click OK
Delete:	To delete an entry on the list, highlight the entry by
	clicking on it. Then, click Delete
Clear:	To clear all entries, click Clear

Click **Save** to save the changes

Quality of Service (QoS)

Setup traffic prioritization tags the video packets to go through network switches and routers with assigned priority. You can set the Differentiated Services Code Point (DSCP) bits on outgoing data streams. The QoS capable network device will forward different data in different priorities. The meaning of the value is different in different DiffServ domains. Consult your network manager for the setup details.






Click **Save** to save the changes

UPnP

Universal Plug-and-Play is a device discovery protocol set. It allows your camera to easily be found, for example, on a Windows operation system.



UPnP		
Enable UPnP:	Check this box to enable UPnP connection.	
Friendly Name:	The name that will be appeared when searched.	


Port Mapping	
Enable Port Mapping:	Check this box to enable UPnP connection.
Port Mapping Mode:	Choose Manual or Auto port mapping.
External Port:	Choose the port number for mapping.

Click **Save** to save the changes

Video Settings

Video Format

Adjust the format of video.




Video Encoding:	Choose the video stream you want to modify. H.264 and MJPEG videos are always streaming and	
MJPEG	can be configured separately.	
Resolution:	H.264	MJPEG
	1280*720P	320*240
	1920*1080P	352*240
	2048*1536	704*480
Bitrate Type:		e bit rate or constant bit on. The default is variable
Video Quality:	Choose the video quality quality.	. The default is medium
Frame Rate:		me rate. The default value Reduce the frame rate to ze.
Max. Bitrate:	Choose the maximum vio Default: 4096	deo sampling bit rate.
I Frame Interval		


Click **Save** to save the changes

Display Settings

Adjust video image quality, lightness, and color settings here.



Brightness:	Use the slider or enter a number (0-100) to adjust the image brightness. Default: 50
Contrast:	Use the slider or enter a number (0-100) to adjust the image contrast. Default: 50
Saturation:	Use the slider or enter a number (0-100) to adjust the color saturation. The greater number means the color will be more saturated. Default: 50
Hue:	Use the slider or enter a number (0-100) to adjust the color shade. Default: 50
Sharpness:	Use the slider or enter a number (0-100) to adjust the image sharpness. Default: 50



Light sensitivities

Smart IR: Smart IR can adjust the strength of infrared lights at night depending on the distance of an object to maintain the maximum IR light distance and while maintaining a clear picture when object is close by. Default: On.

Max. Exposure Time:

1/3 1/6 1/12 1/30 1/60 1/120 1/250 1/500 1/750 1/1000 1/2000 1/4000 1/10000

Adjust this value for exposure time for each picture. You can choose a value between 1/3 second to 1/100,000 second. The default value is 1/30 second exposure time for each picture.

Video Standard: This is the base frequency for the video refresh rate. It is recommended to set to the same frequency of your local video standard (NTSC: 60, PAL: 50). Default: 60Hz.

Day/Night Switch:




Choose whether you want the camera to be set to the day mode (color video) or night mode (IR enhanced black/white video). You can manually set it to day mode or night mode, adjust by lighting (Auto), or pre-define schedule.

Auto:

Switch Time: The time delayed to switch between modes. Longer switch time can prevent unnecessary mode flipping if an object is blocking the light source temporarily. Range: 5-120 seconds, default: 5 seconds.

Schedule:

Use guick selection or enter the time down below. Click **OK** to confirm the time you want to set.



Start Time: The start time for day mode. **Stop Time:** The start time for day mode.

Position adjustments

Mirror:

Horizontal Vertical

Horizontal/Vertical

Default

Choose horizontal, vertical or both to adapt to the physical position of installation.

Image adjustments

Back Light Compensation

Back light compensation: Setup a fixed light source position to compensate and adjust the image in the

and dark.

Digital Wide-Dynamic-Range: Choose the area that you want to enhance (dark area, not light source).

Note: By default, the D-WDR is enabled. Please disable D-WDR to set up back light compensation.



D-WDR: Digital Wide Dynamic Range compensates for the dark area dynamically.

• **D-WDR Level:** The level of compensation. Range: 0-100%, default: 20%.

White Balance:

Automatic Locked Incandescent Lamp(3000K) Warm Light Lamp(4000K) Natural Light(5500K) Fluorescent Lamp(6500K) Choose a color temperature as the white color and compensate the color on the whole image.

Digital Noise Reduction:

Choose the mode of noise reduction.

Normal Mode

Noise Reduction Level: Adjust the effect of digital noise reduction. Range: 0-100%, default: 100%

Expert Mode

Space DNR Level: Adjust the special digital noise reduction with adjacent pixels. Change the range (0-100%) to change the adjacency effect, default: 50% **Time DNR Level:** Adjust the 3D digital noise reduction. Compare and reduce noise between video frames. Range: 0-100%, default: 100%

Click **Reset** to reset the display adjustments

On Screen Display Settings

Display the camera name and the time the video is shooting on the screen



Display
Name: Setup in the device settings (refer to page 26 Device Settings to change the device name.)
Display Date: Check this box to display system time.

Display Week: Check this box to display time of the week.

Time Format: Select 12 or 24-hour time format.

Date Format: Select the date format


Display Mode: Choose how the text will show on the screen.

OSD Size: Select the text size from 16 to 64 or adjusted by screen size automatically.

Move the red box to position the text. Click **Save** to save the changes.

Text Overlay

Display extra information on the screen over the image.



Check Box: Check this box to enable text overlay.

Text Field: Enter the text you want to display. You can enter your local language if you want. The text field allows

maximum 44 English letters or 20 non-English


characters.

Move the red box to position the text.

Click **Save** to save the changes

Privacy Mask

Create a masking area to keep your privacy. You can create up to four independent masking areas by clicking and dragging on the screen.



Enable Privacy Mask: Check this box to enable privacy masking.

Stop Drawing: Click this button to stop drawing.


Clear All: Click this button to clear all the masking areas.

Video Recording



Pre-record: Recording time before trigger event.
Post-record: Recording time after trigger event.
Overwrite: Select Yes to allow older recordings to be overwritten.

Enable Record Check this box and then click Save to enable video recording.



Events

Motion Detection

Set up how the motion detection event will be triggered and what actions will be triggered.



Enable

Check this box to enable motion detection. Click **Save** Motion to save the choice.


Detection:

Enable Check this box to enable motion tracking. Motion Motion tracking is a dynamic display that shows the current Tracking: status of motion detection. The motion tracking is displayed with grids in green. The grid area represents the camera motion is happening. Click Save to save the choices.




Draw Area: Click Draw Area button to start drawing. Click and drag on the area you want to set up the motion detection. You can draw up to 8 different areas. Click Stop Drawing to stop drawing motion detection areas.

The red grids represent the motion detection area.




Sensitivity: Move the slider to adjust detection sensitivity.

Clear All: Click this button to clear all the set up areas.



Arming Schedule

Edit: Click Edit to edit the recording schedule. The Edit Schedule window will pop up.



- 1. Select day of the week you want to edit.
- 2. Select **All Day** or **Customized** schedule of the day.
- 3. Set the time period and the event you want to trigger the video recording **continuous** (always recording) or **motion detection**.
- 4. Click **Select All** or the weekday you want to have the same schedule on different day.
- 5. Click another day of the week by clicking on its tab to set the next schedule. Click **OK** when you have finished your settings.


Actions	
Send Email:	Check this box to send an e-mail notification when
	motion is detected.
Network	Check this box to record video to network storage
Storage:	when motion is detected.
Upload to FTP:	Check this box to send snapshots to an FTP server
	when motion is detected.

Click **Save** to save the changes

Video Tamper

This is to detect if the camera has been tampered with and surveillance is compromised. You can set up tamper proof notifications to alert the system manager to check the camera.






Tamper **Detection:** Check this box to enable tamper detection. Click **Save**

to save the settings.

Draw Area: Click **Draw Area** button to start drawing. Click and drag on the area you want to set up the tamper detection. You can setup only one area for tamper detection. Click **Stop Drawing** to stop drawing motion detection areas. The gray block represents the detection area.




Sensitivity: Move the slider to adjust detection sensitivity.

Clear All: Click this button to clear all the set up areas.

Arming Schedule

Edit: Click **Edit** to edit the recording schedule. The Edit Schedule window will pop up.



- 1. Select day of the week you want to edit.
- 2. Select **All Day** or **Customized** schedule of the day.
- 3. Set the time period and the event you want to trigger the video recording **continuous** (always recording) or **motion detection**.
- 4. Click **Select All** or the weekday you want to have the same schedule on different day.
- 5. Click another day of the week by clicking on its tab to set the next schedule. Click **OK** when you have finished your settings.

Notification

Send Email: Check this box to send an e-mail notification when motion is detected.

Click **Save** to save the changes

Exception

Provide notifications for other system events, set up your notifications here.



Notification

Exception Type: First, choose the exception type, and then choose


the corresponding action.

Send Email: Check this box to send an e-mail notification when

motion is detected.

Snapshot

You can set up your camera to continuously taking snapshots or taking snapshots only when events happening.



Continuous	
Enable:	Check this box to take snapshots continuously.
Format:	Save snapshots in JPEG format
Resolution:	Uses the same resolution set in Video Format for the snapshot resolution.
Quality:	Choose a compression quality for snapshots.


Interval: State the time interval between snapshots. The default interval is 10 seconds.

Event triggered Enable: Check this box to take snapshots when an event is occurred. Format: Save snapshots in JPEG format Resolution: Uses the same resolution set in Video Format for the snapshot resolution. Quality: Choose a compression quality for snapshot. Interval: State the time interval between this series of snapshots. The default interval is 1 second. Capture Number: State how many snapshots you want to take in a single triggered event. Default: 3 pictures.

Click **Save** to save the changes

Email

Set up email accounts for notifications.



Sender	
Sender:	Enter the name to be appeared as the email sender.
Sender's Address:	Enter sender's email address.
SMTP Server:	Simple Mail Transportation Protocol Server address, the outgoing email server address. It may be has

	address as your incoming email server, maybe not. Please ask your email service provider for detail.
SMTP Port:	Service port number for outgoing email.*
Enable SSL:	Check this box if your service provider requires a SSL
	secured connection.
Attach	Check Attach Image if you want to send a snapshot
Image/Interval:	image with the email notification and select the
	interval of snapshots in seconds.
Authentication:	Check this box if your server requires a password in
	order to send email. Most email servers require
	authentication when sending an email.
User name:	Enter the user name of outgoing email account
Password:	Enter the password
Confirm:	Enter the password again to confirm that the
	password was entered correctly.

Click **Save** to save the changes

Receiver	
Receiver 1:	The first receiver's name.
Test Button:	Send test email to Receiver1
Receiver 1's	The first receiver's email address.
Address:	
Receiver 2:	The second receiver's name.
Receiver 2's	The second receiver's email address.
Address:	
Receiver 3:	The third receiver's name.
Receiver 3's	The third receiver's email address.
Address:	

Click **Save** to save the changes

*Note: Many ISPs does not allow service port 25 going through their network. Other popular ports are 587 and 465. Please consult your email service provider and ISP for detail.

Network Storage

Network Storage

Network Storage must be setup before it can be managed. For storage management, please refer to the next section.

The TV-IP312PI supports two formats of network storage file systems: NFS and CIFS. NFS, Network File System, is natively supported by Linux computers and most NAS, Network Attached Storage. CIFS, Common Internet File System, is natively supported by Windows® systems and now is generally supported by Linux. (OS X® file sharing is not standard SMB and not compatible as a network storage disk here.)

You can add up to 8 network storages for your camera. The recordings will subsequently be stored in these spaces. Save video from the first storage and then the next when the first one is full. Click on the entry to change the settings and click Save to save the settings.



No: The sequential number of the network storage. The type of storage. Type: Enter the IP address of your network storage. **Address: File Path:** Enter the shared folder as file path for network storage. You can create a folder under the shared folder and make it a network volume here. Just create the folder and enter the correct path name here. **Capacity:** Enter the size of the disk space you want to assign for this storage. The minimum disk space requirement is 8GB. If you do not want to limit the size and use the full physical disk space, put number 0 in this field. **File System:** Choose between NFS or CIFS for file system. If you assign the network storage on a Windows® computer, set it to CIFS. **User Name:** Enter the user name if the network storage requires user name and password. Enter any non-blank letters if no authentication is required. **Password:** Enter the password to access the network storage. Enter any non-blank letters if no authentication is required.

Click **Save** to save the changes. The camera may reboot to make the network storage available. Go to the next section to format and manage your network storage.

Tip: To create a network storage on your Windows® based system, create a shared folder and then test your set up with another computer. Enter the IP address of the computer here and enter the shared folder name with a leading forward slash. For example, if you have a shared folder named "SMB", enter "/SMB" in the **File Path**.

Storage Management

Network Storage must be setup before it can be managed. To setup storage, please refer to the previous section.



Format: Select a network storage volume and then click Format to format your network storage. This action will format the network volume (shared folder) for video recording. Placeholder files (formatting files) will be created to make sure disk allocation is appropriate and the file searching is optimized.

The volume format is a proprietary user space storage format. Meaning that you visit the shared folder and see some structured files. Please do not modify these files manually. Modifying these files may cause recording and playback problems. Access your recording and system log via the web management user interface to download the recording and snapshots.

Capacity: The total capacity this network storage can use.

Free Space: The free space left for video recording, snapshot and log.


Status: The connection status to the network storage.

Property: This network storage is read only or can be read and write.

Progress: The progress of ongoing task.

Note: The formatting progress depends on the size of the storage and the network bandwidth. It takes a while if you are formatting a big volume or the network connection is not stable.

FTP Server



Enable Snapshot
to FTP:
FTP.

Server Address: Enter the FTP server IP address.

Port: Enter the service port number of the FTP server.

User Check Anonymous if the FTP server does not require authentication. Enter the User Name if the FTP server requires authentication.

Password: Enter the password of the FTP account.

Confirm: Enter the password again to make sure the password was entered correctly.

Directory When saving snapshots on an FTP server, they can be saved in a single place or organized with meaningful directory names.

Save in root directory: You can choose to store all files in the same folder of FTP login.

Save in directory: Structure your folders with camera name or IP address.

Directory: •

- Use Camera Name: Use the camera name to organize the saved files.
- Use Camera IP: Use the camera IP address to organize the saved files.

Regulations

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The availability of some specific channels and/or operational frequency bands are country dependent and are firmware programmed at the factory to match the intended destination. The firmware setting is not accessible by the end user.

<u>RoHS</u>

This product is RoHS compliant.



Europe – EU Declaration of Conformity

This device complies with the essential requirements of the Directive 2004/108/EC and 2006/95/EC. The following test methods have been applied in order to prove presumption of conformity with the essential requirements of the Directive 2004/108/EC and 2006/95/EC:

- EN 60950-1:2006+A11:2009+A1:2010+A12:2011
- IEC 60950-1:2005 (2nd Edition) Am 1:2009
 Safety of Information Technology Equipment



- EN 55022: 2010 Class A
- EN 61000-3-2: 2006 + A1: 2009 + A2: 2009
- EN 61000-3-3: 2008
- EN 50130-4: 2011

Česky [Czech]	TRENDnet tímto prohlašuje, že tento TV-IP312PI je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 2004/108/ES a 2006/95/ES.
Dansk [Danish]	Undertegnede TRENDnet erklærer herved, at følgende udstyr TV-IP312PI overholder de væsentlige krav og øvrige relevante krav i direktiv 2004/108/EF og 2006/95/EF.
Deutsch [German]	Hiermit erklärt TRENDnet, dass sich das Gerät TV-IP312PI in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 2004/108/EG und 2006/95/EG befindet.
Eesti [Estonian]	Käesolevaga kinnitab TRENDnet seadme TV-IP312PI vastavust direktiivi 2004/108/EÜ ja 2006/95/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.
English	Hereby, TRENDnet, declares that this TV-IP312PI is in compliance with the essential requirements and other relevant provisions of Directive 2004/108/EC and 2006/95/EC.
Español [Spanish]	Por medio de la presente TRENDnet declara que el TV-IP312PI cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 2004/108/CE y 2006/95/CE.
Ελληνική [Greek]	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑΤRENDnet ΔΗΛΩΝΕΙ ΟΤΙ TV-IP312PI ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ

	ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 2004/108/ΕΚ, 2006/95/ΕΚ και.
Français [French]	Par la présente TRENDnet déclare que l'appareil TV-IP312PI est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 2004/108/CE, 2006/95/CE et.
Italiano[Italian]	Con la presente TRENDnet dichiara che questo TV-IP312PI è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 2004/108/CE e 2006/95/CE.
Latviski [Latvian]	AršoTRENDnetdeklarē, ka TV-IP312PI atbilstDirektīvas 2004/108/EK un 2006/95/EK būtiskajāmprasībām un citiemar to saistītajiemnoteikumiem.
Lietuvių [Lithuanian]	Šiuo TRENDnet deklaruoja, kad šis TV-IP312PI atitinka esminius reikalavimus ir kitas 2004/108/EB ir 2006/95/EB Direktyvos nuostatas.
Nederlands [Dutch]	Hierbij verklaart TRENDnet dat het toestel TV-IP312PI in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 2004/108/EG en 2006/95/EG.
Malti [Maltese]	Hawnhekk, TRENDnet, jiddikjara li dan TV-IP312PI jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 2004/108/KE u 2006/95/KE.
Magyar [Hungarian]	Alulírott, TRENDnet nyilatkozom, hogy a TV-IP312PI megfelel a vonatkozó alapvető követelményeknek és az 2004/108/EK és a 2006/95/EK irányelv egyéb előírásainak.
Polski [Polish]	Niniejszym TRENDnet oświadcza, że TV-IP312PI jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 2004/108/WE i 2006/95/.
Português [Portuguese]	TRENDnet declara que este TV-IP312PI está conforme com os requisitos essenciais e outras disposições da Directiva2004/108/CE e 2006/95/CE.
Slovensko [Slovenian]	TRENDnet izjavlja, da je ta TV-IP312PI v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive2004/108/ES in 2006/95/ES.
Slovensky [Slovak]	TRENDnettýmtovyhlasuje, že TV-IP312PI spĺňazákladnépožiadavky a všetkypríslušnéustanoveniaSmernice 2004/108/ES a 2006/95/ES.
Suomi [Finnish]	TRENDnet vakuuttaa täten että TV-IP312PI tyyppinen laite on direktiivin2004/108/EY ja 2006/95/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.
Svenska [Swedish]	Härmed intygar TRENDnet att denna TV-IP312PI står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 2004/108/EG och 2006/95/EG.

Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

• TV-IP312PI – 3 Years Warranty

If a product does not operate as warranted during the applicable warranty period, TRENDnet shall reserve the right, at its expense, to repair or replace the defective product or part and deliver an equivalent product or part to the customer. The repair/replacement unit's warranty continues from the original date of purchase. All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of purchase for their return policies.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product by any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase. Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued. An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment. Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees.

WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLECT, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATE, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California.

Some TRENDnet products include software code written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL").

Go to http://www.trendnet.com/gpl or http://www.trendnet.com Download section and look for the desired TRENDnet product to access to the GPL Code or LGPL Code. These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. Please go to http://www.gnu.org/licenses/gpl.txt or http://www.gnu.org/licenses/lgpl.txt for specific terms of each license.

12.23.2016 TV-IP312PI User's Guide

TRENDIET

Product Warranty Registration

Please take a moment to register your product online.

Go to TRENDnet's website at http://www.trendnet.com/register

TRENDnet 20675 Manhattan Place Torrance, CA 90501. USA