


Firmware Upgrade Procedures

1. Save the unzipped firmware file to your PC
2. Go to router's configuration page (default IP is 192.168.10.1)
3. Navigate to the **Admin** section and select **Upgrade Firmware** option



4. Click **Browse** and select the unzipped firmware file
5. Click the **Upload** button
6. Wait until the firmware upload completed and the device reboot

Important! Do not turn off the device or press the reset button while this procedure is in progress.