


## Firmware Upgrade Procedures

1. Save the unzipped firmware file to your PC
2. Go to router's configuration page (default IP is 192.168.10.1)



3. Navigate to the **Maintenance** and **Upgrade Firmware** section.
4. Click **Browse** and select the unzipped firmware file.
5. Click **Upload** and wait until the firmware upload is completed and the device will reboot automatically.