



## Firmware upgrade procedures

1. Unzip the downloaded file to your desktop
2. login to the configuration page (default IP is 192.168.10.1)



3. Go to **Tools** → **Firmware** section



4. Click on **Browse** button and find the unzipped firmware file and click on **Upgrade**
5. Upgrade complete.