


Firmware Upgrade Procedures

1. Save the unzipped firmware file to your PC
2. Go to access point's configuration page (default IP is 192.168.10.100)
3. Navigate to the Tools section and select **Firmware** option



4. Click **Browse** and select the unzipped folder.
5. Select the first firmware file then click **Apply** button
6. Wait until the firmware upload completed and the device reboot.
7. Click **Browse** the unzipped folder again and select the second firmware file then click **Apply** button
8. The firmware upgrade is completed.