


Firmware Upgrade Procedures

1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default IP is 192.168.10.1 or http://tew-817dtr)
4. Click on **Advanced** and click **Setup**, then click **Firmware**.
5. Depending on your web browser, in the **Upload Firmware** section, click **Browse** or **Choose File**.



The screenshot shows a dark-themed interface for uploading firmware. At the top, the title 'Upload Firmware' is displayed. Below the title, there are three main elements: a 'Choose File' button on the left, a 'Browse...' button in the center with the text 'No file selected.' to its right, and a blue 'Upload Firmware' button on the right.

6. Navigate to the folder on your computer where the unzipped firmware file (.bin) is located and select it.
7. Click **Apply**. If prompted, click **Yes** or **OK**. Wait until the firmware upload completed and the device reboots.
8. To finalize the firmware update process you must reset the TEW-814DAP to factory default settings.
9. Log back into the TEW-817DTR, click on the **Advanced** and **Administrator** and click on **Settings Management** section. Under Restore Factory default click on **Load Default**.

Note: You will need to reconfigure and access the router's management page using the predefined settings found on the top or bottom labels.