


Firmware Upgrade Procedure

1. Save the zipped firmware file to your PC.
2. Extract the .zip file to your PC.
3. Make sure you connect your PC directly one of the network (Ethernet) ports on the device via network (Ethernet cable) when upgrading the device firmware.



4. Assign static IP address settings to your PC (ex. 192.168.10.10 / 255.255.255.0) to access the device's web management interface.
5. Using a web browser (ex. Internet Explorer, Firefox, Safari, etc.), login to the device's web configuration page (Default IP Address/Netmask is 192.168.10.200 / 255.255.255.0)
6. Navigate to the **System** section on the left hand side and select **Firmware Upgrade**.



7. In the main window, click on **HTTP Firmware Upgrade**. Click **Browse** and navigate to unzipped folder with the firmware file. Once selected, click the **Upgrade** button.

Firmware Upgrade

<input checked="" type="radio"/> HTTP Firmware Upgrade
Upgrade firmware from file : <input type="text"/> <input type="button" value="Browse...."/>
<input type="button" value="Upgrade"/>
<input type="radio"/> TFTP Firmware Upgrade
TFTP Server IP Address : <input type="text"/>
TFTP firmware file name : <input type="text"/>
<input type="button" value="Upgrade"/>

8. Wait until the firmware upload completed and the device reboot
Important! Do not turn off the device or press the reset button while this procedure is in progress.