

Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the access point's management page (default IP is <http://192.168.10.100>)
Note: You may need to statically assign your computer's IP address to 192.168.10.x in order to access the access point's management page.
4. Click on **Administration** and click on **Firmware**.
5. Depending on your web browser, next to **Select File**, click **Browse** or **Choose File** and select the firmware file (.bin) from the extracted files. Then click the **Upload** button.

Note: In addition, this page displays the access point current firmware version and build date.

Upgrade Firmware	
Firmware Version	v1.10
Build Day	Tue Dec 17 18:59:22 CST 2013
Select File	<input type="text"/> <input type="button" value="Browse..."/>

6. Wait until the firmware upload has completed and the device reboots.
7. The firmware upgrade is complete.