


1. Extract the driver files from the downloaded .zip file.
2. Locate the file name **RTUNICv1.0.17.pkg** and double click on it to run the installation process



3. Follow the instructions to install the driver. Click **Restart** to restart your computer to finalize the driver installation.