

1. Extract the driver files from the downloaded .zip file.
2. Locate the file name **TUC-ET5G\_Driver\_32bit.msi** and double click on it to run the installation process.
3. Follow the instructions to install the driver and click **Finish** when the installation is complete.