

Internet Camera Server Firmware Upgrade Procedure


For Model: TV-IP110, TV-IP110W, TV-IP212, TV-IP212W, TV-IP312, TV-IP312W, TV-IP410, TV-IP410W, TV-IP422, TV-IP422W

Warning:

- Always upgrade firmware by using a wired connection.
- Do not interrupt the connection while doing the firmware upgrading

Note: The firmware procedure is based on the TV-IP212W. The procedure is the same but with slightly different screenshots.


1. Download the firmware file from www.trendnet.com. Save the firmware on your computer.
The firmware file name ends with *.pck extension.
2. Go to Internet Explorer and type in the IP address of your camera
e.g. <http://192.168.10.30>




3. Enter the username & password
By default, the username & password is admin/admin




4. Click **Setup**




5. Click **Tools**




6. Check the firmware version first. Click **Browse** to choose the firmware file. Once the firmware is ready, click **Upgrade**



7. Wait 30 seconds for the device reboot.



8. After 30 seconds, click **Tools** again to check the firmware version.



9. The firmware upgrade is now completed.