



## Firmware Update Procedures


1. Unzip the downloaded firmware file to your desktop
2. Log into the camera and go to Advanced → System → Maintenance section




3. Go to firmware section and click on Browse to select the new firmware to load



- Select the unzipped firmware file and click on Upgrade, the camera will reboot after firmware is loaded.



- When the camera finish loading, it will show up as inactive in the Utility, please double click on the IP address to access the camera, setup a new password then the camera is back to active.



- Firmware upgrade is complete.