



Firmware Update Procedures


1. Unzip the downloaded firmware file to your desktop
2. Log into the NVR and go to Advanced ★ System ★ Maintenance section




3. Go to firmware section and click on Browse to select the new firmware to load



4. Select the unzipped firmware file and click on Upgrade, the NVR will reboot after firmware is loaded.



5. When the NVR finish loading, it will show up as inactive in the Utility, please double click on the IP address to access the NVR, setup a new password then the NVR is back to active.



6. Firmware upgrade is complete.