

TEW-648UB / TEW-649UB Mac OS X Installation

Minimum System Requirements

- USB Port: 1.1 or 2.0

Supported Operating Systems	CPU	Memory
Mac OS X (10.6)	Intel Processor	1GB RAM or above
Mac OS X (10.5)	867MHz or above	512MB RAM or above
Mac OS X (10.4)	333MHz or above	256MB RAM or above

Note: DO NOT install the TEW-648UB / TEW-649UB in the computer until instructed to do so.

1. Go to Mac folder on the Utility and Driver CD-ROM

2. Double click on the TEW-648UB / TEW-649UB_MacOS_X.dmg icon



TEW-648_649UB_Mac_OS_X.dmg

3. Double click on the icon for your operating system.



TEW-648_649UB_(Intel)MacOS10.4...I_1.7.8.dmg



TEW-648_649UB_(Intel)MacOS10.5...I_1.7.8.dmg



TEW-648_649UB_(Intel)MacOS10.6...I_1.7.8.dmg



TEW-648_649UB_(PowerPC)M...I_1.7.8.dmg



TEW-648_649UB_(PowerPC)M...I_1.7.8.dmg


4. Double click on the Installer.mpkg icon




Installer.mpkg



5. Click **Continue**.



6. Click **Continue**.




7. Select the desired language from the dropdown menu.

8. Click **Continue**.


To continue installing the software, you must agree to the terms of the software license agreement.

Click Agree to continue or click Disagree to cancel the installation.

9. Click **Agree**.




10. Select a destination and then click **Continue**.



11. Click **Install**.


12. When the **Authenticate** screen appears, enter the **Name** and **Password** for your computer and then click **OK**.



13. Click **Continue Installation**.



13. Click **Restart**.



14. Connect the wireless adapter to an available USB port on your




15. Drivers will install automatically.

Hardware installation is now complete.

Using the Wireless Adapter

1. Click **OK**.



2. Double click on the System Preferences icon on the Dock.




3. Double click on the Network icon.



4. Click **OK**.



5. Select the adapter from the dropdown list.




6. Click **Apply Now**.


7. Double click on the Wireless Utility icon on the Dock.



8. Click **Available Network**, select the SSID (Wireless Network Name) and then click **Add to Profile**.



9. If Encryption is enabled on your wireless network (e.g. access point or wireless router), select the type of **Network Authentication** and **Data Encryption**, enter the network encryption, confirm (retype) the network key and then click **OK**



Wireless configuration is now complete.