

TFM-PCIV92A(B1) Microsoft Windows 7 Installation

Minimum System Requirements


- Computer with an available PCI slot Version 2.2
- CPU: 1GHz or above
- Memory: 1GB RAM or above
- Hard Driver Space: 4MB or above

Note:


1. DO NOT install the TFM-PCIV92A in the computer until instructed to do so.
2. You will need to uncompress the drivers after you download it.
3. These instructions are only for TFM-PCIV92A version B1. Version A does not support Windows 7.

1. Go to <http://www.trendnet.com/downloads>. From the Select Product dropdown list, scroll down until you see TFM-PCIV92A. Then click Go. Select the hardware version B1, click the Windows 7 driver link and save the drivers to your computer.


2. Browse the Windows 7 folder. Go to the x64 folder if you have 64-bit Windows 7. Go to the x86 folder if you have 32-bit Windows 7.



3. Double click on the Setup icon



4. Click OK.




5. Shutdown your computer.

6. Open your computer's case.




7. Insert PCI Card firmly into an available PCI Card slot of desktop PC and then turn ON the computer and wait until the Windows desktop appears.



8. Drivers will install automatically

9. Connect a telephone wire from the modem's LINE port to a phone jack.



Your installation is now complete.