



## Guia de Instalação Rápida

**TE100-S5Pplus**  
**TE100-S8P**

Português .....	1
1. Antes de Iniciar .....	1
2. Instalação de Hardware .....	2
Especificações Técnicas .....	11
Troubleshooting .....	13

# 1. Antes de Iniciar




## Conteúdo da Embalagem

- TE100-S5Pplus/TE100-S8P
- Guia de Instalação Rápida
- Adaptador de Tensão AC

## Requisitos do Sistema

- Computador com adaptador de Rede instalado
- A superfície deve suportar pelo menos 1 Kg para o Switch.
- A tomada deve estar a no máximo 1.82 metros do Switch.
- Visualmente inspecione o jack de alimentação DC para certificar-se de que está seguramente conectado ao adaptador de tensão.
- Certifique-se de que há dissipação apropriada de calor do Switch e ventilação adequada em volta do mesmo.
- Não coloque objetos pesados em cima do Switch

## Aplicação



## 2. Instalação de Hardware

1. Conecte o **Adaptador de Tensão AC** ao TE100- S5PEplus/ TE100-S8P e em seguida a uma tomada.



2. Conecte um cabo de rede RJ-45 CAT-5 do computador a uma porta Ethernet disponível do TE100-S5Pplus/ TE100-S8P.



Geral	
<b>Padrões</b>	EEE 802.3 10BASE-T Ethernet IEEE 802.3u 100BASE-TX Fast Ethernet ANSI/IEEE 802.3 NWay Auto Negociação IEEE 802.3x Controle de fluxo Full-Duplex
<b>Protocolo</b>	CSMA/CD
<b>Taxa de Transferência de Dados</b>	Ethernet: 10Mbps (Half-Duplex), 20Mbps (Full-Duplex) Fast Ethernet: 100Mbps (Half-Duplex), 200Mbps (Full-Duplex)
<b>Topologia</b>	Estrela
<b>Cabos de Rede</b>	Ethernet: UTP/STP CAT-3, 4, 5 Fast Ethernet: UTP/STP CAT-5, 5e, 6
<b>Número de portas</b>	5 ou 8 portas Auto-MDIX 10/100 Mbps com Auto Negociação

Performance	
<b>Método Transmissão</b>	Store-and-Forward
<b>Tabela Endereço MAC</b>	TE100-S5Pplus: 1K Entradas por Dispositivo TE100-S8P: 1K Entradas por Dispositivo
<b>Aprendizado Endereço MAC</b>	Atualização Automática

## Física e Ambiental

<b>Entradas DC</b>	7.5 VDC, 1 A
<b>Consumo de Energia</b>	TE100-S5Pplus: 2 W (Máx) TE100-S8P: 3.6 W (Máx)
<b>Temperatura</b>	Operação: 0° ~ 40° C Armazenagem: -10° ~ 70° C
<b>Umidade</b>	Operação: 10% ~ 90% Armazenagem: 5% ~ 90%
<b>Dimensões</b>	TE100-S5Pplus: 124 x 86 x 40 mm TE100-S8P: 165 x 114 x 44 mm
<b>Peso</b>	TE100-S5Pplus: 118g TE100-S8P: 236g
<b>Certificados</b>	FCC, CE

**P1: Depois de conectar o Switch à tomada, os LEDs não acenderam.**

**R1:** Verifique a conexão do adaptador de tensão externo ao TE100- S5Pplus/ TE100-S8Pplus e a tomada. Também verifique se a tomada está recebendo energia.

**P2: Quando eu conecto um computador à porta do Switch, o LED LINK/ACT liga, mas o LED 100 Mbps permanece desligado.**

**R2:** Quando o LED 100 Mbps permanece desligado, a velocidade de conexão do computador é de 10 Mbps.

**P3: Depois de conectar meus PCs ao Switch, não consigo compartilhar arquivos.**

**R3:** Primeiro, verifique os LEDs no Switch. Certifique-se de que o LED LINK/ACT está aceso. Segundo, verifique o cabo de rede. O comprimento mínimo do cabo é de 1.5 metros e o comprimento máximo do cabo é de 100 metros. Terceiro, desabilite qualquer software com programa firewall. Quarto, verifique se você tem arquivo e impressora compartilhada habilitados. Favor entrar em contato com o suporte da Microsoft para mais informações.

**P4: Depois de conectar meus PCs ao Switch, eu só consigo entrar na Internet de um computador.**

**R4:** O Switch não foi projetado para compartilhar a Internet entre múltiplos computadores. Você precisa ter um roteador de Internet.

Se você ainda encontrar problemas ou tiver alguma pergunta referente ao TE100- S5Pplus/TE100-S8Pplus, favor entrar em contato com o Departamento de Suporte Técnico da Trendnet.

## Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

### **TE100-S5Pplus/TE100-S8P - 5-Year Warranty**

If a product does not operate as warranted above during the applicable warranty period, TRENDnet shall, at its option and expense, repair the defective product or deliver to customer an equivalent product to replace the defective item. All products that are replaced will become the property of TRENDnet. Replacement products may be new or reconditioned.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product through any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet office within the applicable warranty period for a Return Material Authorization (RMA) number, accompanied by a copy of the dated proof of the purchase. Products returned to TRENDnet must be pre-authorized by TRENDnet with RMA number marked on the outside of the package, and sent prepaid, insured and packaged appropriately for safe shipment.



WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACEMENT. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California.

Note: AC/DC Power Adapter, Cooling Fan, and Power Supply carry 1-Year Warranty

## Certifications

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



**NOTE:** THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

## ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.



## TRENDnet Technical Support

### US • Canada

**Toll Free Telephone:** 1(866) 845-3673  
24/7 Tech Support



### Europe (Germany • France • Italy • Spain • Switzerland • UK)

**Toll Free Telephone:** +00800 60 76 76 67  
English/Espanol - 24/7  
Francais/Deutsch - 11am-8pm, Monday - Friday MET

### Worldwide

**Telephone:** +(31) (0) 20 504 05 35  
English/Espanol - 24/7  
Francais/Deutsch - 11am-8pm, Monday - Friday MET

## Product Warranty Registration

Please take a moment to register your product online.  
Go to TRENDnet's website at <http://www.trendnet.com>

**TRENDnet**<sup>®</sup>  
20675 Manhattan Place  
Torrance, CA 90501  
USA