

Firmware Upgrade Procedure

Note: It is advisable to save current configuration to a file and reload after the firmware upgrade. A firmware upgrade may reset the device back to factory settings and all current settings would be lost.

1. Save the unzipped firmware file to you PC
2. Go to the device's configuration page (default IP is 192.168.0.1)
3. Navigate to the **Firmware Upgrade** page (System > Firmware Upgrade)
4. Click **Browse** and select the unzipped firmware file (.Hex)



The screenshot shows a web interface titled "Firmware Upgrade". It contains two main sections:

- Backup Firmware to File:** A section with a "Backup" button.
- Upload Firmware from File:** A section with a text input field, a "Browse..." button, and an "Upload" button.

5. Click the **Upload** button to load the firmware
6. Wait until the firmware upload is completed and the device reboots
7. The firmware upgrade is completed