


Firmware Upgrade Procedures

1. Save the unzipped firmware files to your PC (files does not need to be loaded in any order.)
2. Go to router's configuration page (default IP is 192.168.10.100)
3. Navigate to the **Tools** section and select **Firmware** option



The screenshot shows a web-based configuration page titled "Firmware". Below the title, there is a paragraph of instructions: "You can upgrade the firmware of the router in this page. Ensure, the firmware you want to use is on the local hard drive of your computer. Click on Browse to browse and locate the firmware to be used for your update." Below this text is a form with a label "Firmware File:" followed by a text input field and a "Browse..." button. At the bottom right of the form, there are two buttons: "Apply" and "Cancel".

4. Browse and select the unzipped firmware file the click Apply button to load
5. Wait until the firmware upload completed and the device reboot.
6. Repeat steps 4 and 5 to load the other firmware file.
7. The firmware upgrade is completed.