


## Firmware Upgrade Procedures

1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
  - a. Make sure to remember the location where the extracted file will be saved.
3. Open your web browser and enter <http://tew-680mb.trendnet> or <http://192.168.10.110> into the address bar (default settings).
4. You will be prompted for username and password (“admin” is the default setting for both username and password).
5. Navigate to the **Administrator** section and select **Upload Firmware** option



6. Click **Browse** and select firmware file (.bin) in the extracted file and then click **Apply** button to load
7. Wait until the firmware upload is completed and the device reboots.
8. The firmware upgrade is completed.