


Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default URL: http://tew-752dru or default IP is 192.168.10.1)
4. Navigate to the **Tools** section and select **Firmware** option.
5. Click **Browse** and select firmware file (.bin) from the extracted files and click the **Upload** button to start the firmware upgrade process.



Firmware Upgrade

Note: Some firmware upgrades will reset the configuration options to the factory defaults. Before performing an upgrade, be sure to save the current configuration.

To upgrade the firmware, your PC must have a wired connection to the router. Enter the name of the firmware upgrade file and click on the Upload button.

Upload

6. Wait until the firmware upload has completed and the device reboots.
7. The firmware upgrade is complete.