


Firmware Upgrade Procedures


1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default IP is 192.168.10.1)
4. Click on the **Advanced** tab.



5. Click on the **Administrator** section and click on **Upload Firmware**.



6. Depending on your web browser, in the **Upload Firmware** section, click **Browse** or **Choose File**.

A form titled "Upload Firmware". It has a "Location" label next to a text input field. To the right of the input field is a "Browse..." button. At the bottom of the form are two buttons: "Apply" and "Cancel".

7. Navigate to the folder on your computer where the unzipped firmware file (.bin) is located and select it.
8. Click **Apply**. If prompted, click **Yes** or **OK**. Wait until the firmware upload completed and the device reboots.
9. To finalize the firmware update process you must reset the TEW-818DRU to factory default settings.
10. Log back into the TEW-818DRU, click on the **Advanced** tab. In **Administrator** section click on **Settings Management**. Click **Load Default** in **Load Factory Default** section.

Note: You will need to reconfigure and access the router's management page using the predefined settings found on the side or bottom labels.