

## Firmware Upgrade Procedures


1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
  - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default IP is 192.168.10.1)
4. Click on the **Advanced** tab.



5. Click on the **Administrator** section and click on **Upload Firmware**.



6. Depending on your web browser, in the **Upload Firmware** section, click **Browse** or **Choose File**.

A dark grey dialog box titled "Upload Firmware". It has a "Location" label on the left, an empty text input field in the middle, and a "Browse..." button on the right. At the bottom, there are two blue buttons: "Apply" and "Cancel".

7. Navigate to the folder on your computer where the unzipped firmware file (*.bin*) is located and select it.
8. Click **Apply**. If prompted, click **Yes** or **OK**. Wait until the firmware upload completed and the device reboots.
9. The firmware upgrade is completed.