


Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default URL: <http://tew-822dre> or default IP address <http://192.168.10.100>)
4. Navigate to the **Maintenance** section and click **Firmware Upgrade**.



5. Under **Select File**, click **Browse** (or **Choose File**) and select the firmware file (.bin) from the extracted files and click the **Upload** button to start the firmware upgrade process.
6. Wait until the firmware upload has completed and the device reboots.
7. The firmware upgrade is complete.