


## Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
  - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the switch configuration page  
Default URL/IP address <http://192.168.10.200>  
Default User Name: admin      Default Password: admin
4. Navigate to the **Management** section, click on **Maintenance**, and click on **Firmware**.
5. Under the **Upgrade Firmware** section, click **Browse** or **Choose File** and select firmware file (.fw) from the extracted files and click the **Upgrade** button to start the firmware upgrade process.



The screenshot shows a web interface for firmware management. At the top, there's a 'Maintenance' header. Below it, a navigation bar contains 'Configuration', 'Firmware' (which is highlighted in blue), and 'Reboot'. Under the 'Firmware' section, there's a sub-header 'Upgrade Firmware'. At the bottom, there's a 'File path' label, a 'Choose File' button, and the text 'No file chosen'. To the right of this is a large blue 'Upgrade' button.

6. Wait until the firmware upload has completed and the device reboots.
7. The firmware upgrade is complete.