

Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page
Default URL/IP address <http://192.168.10.200>
Default User Name: admin Default Password: admin
4. Navigate to the **Tools** section, click on **Firmware Upgrade** and select the **via HTTP** option.
5. Click **Browse** and select firmware file (.hex) from the extracted files and click the **Apply** button to start the firmware upgrade process.

Firmware Upgrade via HTTP

Firmware Upgrade via HTTP Settings

Image Version:	1.00.10	
Firmware File:	<input type="text"/>	<input type="button" value="Browse..."/>

Note: System will reset automatically after burning image to flash.

6. Wait until the firmware upload has completed and the device reboots.
7. The firmware upgrade is complete.