



## Quick Installation Guide



**TU2-ETG**  
H/W: V1.3R

# Table of Contents

Français .....	1
1. Avant propos .....	1
2. Procéder à l'installation .....	2
Troubleshooting .....	4

# 1. Avant propos




## Contenu de l'emballage

- TU2-ETG
- CD-ROM Pilote
- Guide d'installation rapide en multilingue

## Configuration du système

- Lecteur de CD-ROM
- Port USB: 2.0 ou 1.1
- Microprocesseur : 300 MHz ou supérieur/ 800 MHz ou supérieur (Window Vista)
- Mémoire: 256 MB RAM ou supérieur/ 512 MB RAM ou supérieur (Window Vista)
- Windows 2000/XP/Vista

## Application




## 2. Procéder à l'installation

Remarque : Ne branchez pas le TU2-ETG à votre ordinateur avant d'en recevoir l'instruction.

1. Insérez le **CD-ROM du pilote** dans le lecteur de CD-ROM de votre ordinateur.


2. Cliquez sur **Exécuter Autorun.exe** (Windows Vista uniquement).




3. Cliquez ensuite sur **Install Driver** (Installer pilote) Et Cliquez ensuite sur votre système d'exploitation.



4. Cliquez sur **Next**. Ensuite suivez les instructions de l'**InstallShield Wizard**.



5. Cliquez ensuite sur **Terminer (Finish)**.



6. Branchez l'adaptateur à un port USB disponible sur votre ordinateur.



7. Les pilotes s'installeront automatiquement.

8. Branchez un câble RJ-45 Cat-5e ou Cat-6 entre l'adaptateur et le switch, le routeur ou le modem câble/DSL.



**L'installation est maintenant complète.**

Pour obtenir des informations détaillées sur la configuration et les paramètres avancés du TU2-ETG, veuillez consulter le Guide de l'utilisateur sur le pilote et sur le CD-ROM.

### Enregistrez votre produit

Afin d'être sûr de recevoir le meilleur niveau de service clientèle et le meilleur support possibles, veuillez prendre le temps d'enregistrer votre produit en ligne sur:

[www.trendnet.com/register](http://www.trendnet.com/register)

Nous vous remercions d'avoir choisi Trendnet

**Q1: Can I connect or disconnect the TU2-ETG while the computer is on?**

**A1:** Yes, you can connect or disconnect the TU2-ETG while the computer is on because the USB interface is Plug-and-Play compliant and hot-pluggable.

**Q2: Windows is unable to recognize my hardware. What should I do?**

**A2:** First, make sure your computer meets the minimum requirements as specified in Section 1 of this Quick Installation Guide. Second, try plugging the adapter into a different USB port.

**Q3: Windows recognizes my new hardware, but I'm unable to connect to my network. What should I do?**

**A3:** First, verify that the network cable is securely connected from your switch or router to your adapter. Second, verify that the LEDs on your adapter are lit. Third, verify that the TCP/IP settings are set to **Obtain an IP address automatically**.

**Q4: When I connect the adapter to a gigabit switch, I am not getting gigabit speeds. What should I do?**

**A4:** Make sure you are using CAT-5e or CAT-6 Ethernet Cables. Some CAT-5 cables are not rated to run in Gigabit.

If you still encounter problems or have any questions regarding the **TU2-ETG**, please refer to the User's Guide included on the Driver CD-ROM or contact TRENDnet's Technical Support Department.

## Certifications

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



**NOTE:** THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

### ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.



## Product Warranty Registration

Please take a moment to register your product online.  
Go to TRENDnet's website at <http://www.trendnet.com/register>

**TRENDnet**<sup>®</sup>  
20675 Manhattan Place  
Torrance, CA 90501  
USA