



Lühike paigaldusjuhend



TU2-EX12
1.01

Eesti	1
1. Enne alustamist	1
2. Riistvara paigaldamine	2
.....	
Tehnilised andmed	3
Tõrkeotsing	4



Kontrolli pakendi sisu:

- TU2-EX12 (12 meetrit)
- Mitmekeelne lühike paigaldusjuhend

Minimaalsed nõuded süsteemile


- Arvuti millel on vaba USB 1.1 või 2.0 port

Toetatud operatsioonisüsteemi	Keskprotsessor	Mälu
Windows 7 (32/64-bit)	1GHz või rohkem	1GB RAM või rohkem
Windows Vista (32/64-bit)	800MHz või rohkem	512MB RAM või rohkem
Windows XP (32/64-bit)/ 2000	300MHz või rohkem	256MB RAM või rohkem
Mac OS X (10.6)	Intel Processor	1GB RAM või rohkem
Mac OS X (10.5)	867MHz või rohkem	512MB RAM või rohkem
Mac OS X (10.4)	333MHz või rohkem	256MB RAM või rohkem
Mac OS X (10.1-10.3)	300MHz või rohkem	256MB RAM või rohkem

2. Riistvara paigaldus

1. Ühendage TU2-EX12 USB-A isast tüüpi konnektor teie arvuti vabasse USB porti.

2. Arvuti hakkab automaatselt avastama ja installima draiverid.



3. Ühendage USB välisseade TU2-EX12 USB A emast tüüpi konnektoris.

Paigaldamine on nüüd lõpetatud.

Riistvara	
Liides	USB 2.0, 1.1, 1.0 0 ühilduv (tüüp A)
Ülekande kiirus	Kõrgeim kiirus: 480Mbps Täiskiirus: 12Mbps Madal kiirus: 1.5Mbps
Konnektor	USB Tüüpi A Isane → Emaseks
Kaabli pikkus	12 meetrit
Max vahemaa	36 meetrit
Raskus	430g
Temperatuur	Töötamiseks: 0° ~ 60° C (32° ~ 140° F) Ladustamiseks: -20° ~ 85° C (-4° ~ 185° F)
Niiskus	90% maksimaalne (mittekondenseeruv)
Sertifikaadid	FCC, CE

1. Mu arvuti ei tuvasta minu USB välisseadet kui ma ühendan selle TU2-EX12. Mida ma peaksin tegema?

1. Veenduge, et teie arvuti vastab nõuetele nagu on määratletud 1. jaos.
2. Ühenduge **Device Manager** abil ja kontrollige, et USB seade on vastuvõtvast arvutis korralikult paigaldatud
 1. Et pääseda Windows 7 **Device Manageri**, klõpsake alumises vasakus nurgas Windowsi ikoonil, klõpsake **Computer**, klõppige **System Properties** ja seejärel nuppu **Device Manager**. Topeltklõpsake **Universal Serial Bus Controllers**. Veenduge, et Generic USB Hub on loetletud ja puudub kollane küsimärk või hüüumärk.
 2. Et pääseda **Windows Vista Device Manager**, paremklõpsake **Computer**, klõppige **Properties** ja seejärel klõppige **Device Manager**. Topeltklõpsake **Universal Serial Bus Controllers**. Veenduge, et Generic USB Hub on loetletud ja puudub kollane küsimärk või hüüumärk.
 3. Et pääseda Windows XP Device Manageri, paremklõpsake ikoonil **My Computer**, klõpsake **Properties** klõppige Hardware sakil ja seejärel klõpsake **Device Manager**. Paremklõpsake **My Computer** → **Properties**. Topeltklõpsake **Universal Serial Bus Controllers**. Veenduge, et **Generic USB Hub** on loetletud ja puudub kollane küsimärk või hüüumärk.
 4. Klõppige **Hardware**, siis **Device Manager**.
3. Proovige ühendada seade mõnda teise USB porti.

2. Minu USB välisseade andmeedastuskiirus muutub väiksemaks kui 480Mbps, kui see on ühendatud läbi TU2-EX12. Mida ma peaksin tegema?

1. Veenduge, et TU2-EX12 on ühendatud teie arvuti USB 2.0 porti.
2. Veenduge, et teie USB välisseade toetab USB 2.0.

3. Kas ma saan kaskadeerida 2 või rohkem TU2-EX12 koos?

Te saate kaskaadis kasutada ühtekokku 3 TU2-EX12 seadet koos.

Kui Teil esineb endiselt probleeme või on küsimusi TU2-EX12 kohta, võtke ühendust TRENDneti tehnilise toe osakonnaga.

Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

TU2-EX12 - 2 Years Limited Warranty **AC/DC Power Adapter, Cooling Fan and Power Supply carry a 1 year limited warranty**

If a product does not operate as warranted during the applicable warranty period, TRENDnet shall reserve the right, at its expense, to repair or replace the defective product or part and deliver an equivalent product or part to the customer. The repair/replacement unit's warranty continues from the original date of purchase. All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of-purchase for their return policies.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product by any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase. Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued. An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment. Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees.

WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATE, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California.

Some TRENDnet products include software code written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL").

Go to <http://www.trendnet.com/gpl> or <http://www.trendnet.com> Download section and look for the desired TRENDnet product to access to the GPL Code or LGPL Code. These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. Please go to <http://www.gnu.org/licenses/gpl.txt> or <http://www.gnu.org/licenses/lgpl.txt> for specific terms of each license.

PWP05202009v2

Sertifikaadid:

Seade on testitud ning vastab FCC ja CE reeglitele.

Seade vastab järgmistele tingimustele:

(1) Seade ei tohi põhjustada ohtlikke häireid.

(2) Seade peab võtma vastu kõiki signaale, sealhulgas signaale, mis võivad põhjustada soovimatuid häireid seadme töös.



Elektri- ja elektroonikatoodete jäätmeid ei tohi ära visata koos olmejäätkeid. Abivahendite olemasolu korral palume ümbertöötlemiseks sorteerida. Jäätmete ümbertöötlemise kohta küsige nõu oma kohalikul jaemüüjalt.



MÄRKUS: TOOTJA EI VASTUTA ÜHEGI TV VÕI RAADIO HÄIRE EEST, MIS ON PÕHJUSTATUD SEADME LUBAMATUST ÜMBEREHITAMISEST. IGASUGUNE ÜBERMODIFITSEERIMINE TÜHISTAB AUTORIVASTUTUSE SEADMELE.



Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com/register>