














1. Extract the driver files from the downloaded .zip file.
2. Locate the file name **setup.exe** and double click on it to run the installation process.

	data2.cab	11/11/2018 6:41 PM	WinRAR archive	1 KB
	EngLangID.txt	11/11/2018 6:41 PM	Text Document	1 KB
	InstCtrl.txt	11/11/2018 6:41 PM	Text Document	1 KB
	InstOpt.txt	11/11/2018 6:41 PM	Text Document	1 KB
	ISSetup.dll	11/11/2018 6:41 PM	Application extens...	792 KB
	layout.bin	11/11/2018 6:41 PM	BIN File	2 KB
	setup.exe	11/11/2018 6:41 PM	Application	1,176 KB
	setup.ini	11/11/2018 6:41 PM	Configuration sett...	3 KB
	setup.inx	11/11/2018 6:41 PM	InDesign XML Inte...	273 KB
	setup.isn	11/11/2018 6:41 PM	ISN File	69 KB
	setup.iss	11/11/2018 6:41 PM	ISS File	1 KB
	setupctrl.txt	11/11/2018 6:41 PM	Text Document	1 KB



3. Follow the instructions to install the driver and click **Finish** when the installation is complete.