



TRENDnet



Quick Installation Guide



**TV-IP301
TV-IP301W**

Table of Contents

Français	1
1. Avant de commencer	1
2. Installation du matériel	2
3. Configuration de la Webcam	3
Troubleshooting	5

1. Avant de commencer




Contenu de l'emballage

- TV-IP301/TV-IP301W
- Guide d'installation rapide
- Support métallique
- CD-ROM d'utilités
- Adaptateur secteur
- 1 Antenne amovible 2dBi (TV-IP301W)

Configuration du système

- Ethernet 10/100Mbps
- Microprocesseur : Intel Pentium 1GHz ou supérieur
- Mémoire 256 MB ou supérieur
- Résolution VGA : 800 x 600 ou supérieure
- Navigateur Internet : Internet Explorer 5.0 ou ultérieur

Application



2. Installation du matériel

1. Installez la Webcam sur le support métallique.



2. Connectez l'Antenne. (TV-IP301W)



3. Branchez un câble réseau RJ-45 depuis un Switch/Routeur vers le port **Ethernet** de la Webcam.



4. Branchez l'adaptateur secteur AC à la Webcam et ensuite à une prise de courant.

3. Configuration de la Webcam

Remarque : Il est recommandé de configurer la Webcam depuis un ordinateur câblé. Avant de pouvoir configurer la Webcam, une adresse IP statique doit être assignée à l'adaptateur réseau de votre ordinateur dans le sous-réseau de 192.168.1.x. L'adresse IP par défaut de la Webcam étant 192.168.1.30, assurez qu'aucun autre périphérique réseau n'a reçu la même adresse IP. (Consultez la rubrique « Dépannage » pour configurer les paramètres TCP/IP de votre PC.)

1. Ouvrez votre navigateur Internet, tapez **http://192.168.1.30** dans la barre d'adresse, et appuyez sur **Enter**.




2. Saisissez le nom d'utilisateur et le mot de passe, ensuite cliquez sur .
Nom d'utilisateur: **admin**
Mot de passe: **admin**



3. Cliquez sur **Système** et sur **Réseau**. Configurez les paramètres réseau afin que le sous-réseau soit identique à celui de votre réseau. Cliquez ensuite sur **Enregistrer**.



4. Cliquez sur **Système** et ensuite sur **Sans fil**. Configurez vos paramètres sans fil afin qu'ils correspondent aux paramètres réseau sans fil et cliquez ensuite sur **Enregistrer**. (Uniquement pour le TV-IP301W)



Remarque : Le TV-IP301W ne fonctionnera sans fil jusqu'à ce que vous débranchez le câble Ethernet à l'arrière de la Webcam.

5. Cliquez sur **Live Show Active X**.



L'installation est maintenant complète.

Remarque : Si vous désirez des informations détaillées sur la configuration et les paramètres avancés du **TV-IP301/TV-IP301W**, veuillez consulter la rubrique **Dépannage**, le guide de l'utilisateur sur CD-ROM ou le site Internet de Trendnet sur <http://www.trendnet.com>.

Troubleshooting

Q1: How do I configure TCP/IP settings on my computer?

1. Go into the **Control Panel** and double-click the **Network Connections** icon, and then right-click the **Local Area Connection** icon and then click **Properties**.



2. Click **Internet Protocol (TCP/IP)** and then click **Properties**. Then click on **Use the following IP address**, and make sure you assign your network adapter an IP address in the subnet of 192.168.1.x.



Q2: The image is blurry. How do I fix this?

A2: You can adjust the Internet Camera's focus by rotating the lens.

Q3: When I click on Live Show Active X, the image does not load?

A3: First, make sure that you are using a browser that supports Active X. Second, make sure that Active X is installed.

Q4: How do I connect the TV-IP301W to my wireless router or access point?

A4: Make sure that you configure the camera to have the same SSID, encryption mode and key (if enabled). Follow the instructions in section 2 to configure the camera with the SSID and encryption key.

Q5: After I successfully configured the TV-IP301W to match my wireless network settings, I can not connect to the camera.

A5: First, verify that the wireless settings match your wireless network settings. Second, verify in the wireless section of the browser configuration that the **Disable Wireless Communication** option is not checked. Third, make sure to disconnect the Ethernet cable from the camera and verify that the **LINK** LED is blinking green.

If you still encounter problems or have any questions regarding the **TV-IP301**/
TV-IP301W, please contact TRENDnet's Technical Support Department.

Certifications

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.



TRENDNET

TRENDnet Technical Support

US • Canada

Toll Free Telephone: 1(866) 845-3673

24/7 Tech Support



Europe (Germany • France • Italy • Spain • Switzerland • UK)

Toll Free Telephone: +00800 60 76 76 6

Worldwide

Telephone: +(31) [0] 20 504 05 35

English/Espanol - 24/7

Francais/Deutsch - 11am-8pm, Monday - Friday MET

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com>

TRENDNET

3135 Kashiwa Street
Torrance, CA 90505
USA