

TV-IP572 series / TV-IP672series

Camera Firmware Upgrade Procedures

Warning:


- Always upgrade firmware with a wired connection.
- Do not interrupt the connection while doing the firmware upgrading
- Save your configuration before firmware upgrade

Note:


- 1) TV-IP572P is used for below procedures; other cameras follow the similar route.
- 2) It is necessary to perform a factory reset after the firmware upgrade. If you would like to keep your original setting, please back up your configuration first before upgrading the firmware.

Firmware Upgrade


1. Download and unzip the firmware file from www.trendnet.com/downloads . Save the firmware on your computer. The firmware file name ends with *.bin.
2. Open a browser and go to your camera's IP address (default is 192.168.10.30 if you do not have a DHCP server)




3. Enter the username & password (By default, the username & password is admin/admin)




4. Go to **Setup** page, **Tools** tab then **Firmware Upgrade** option



5. Click **Browse** to select the unzipped firmware file then click **Upgrade**.



6. After camera reboots, click **Firmware Upgrade** tab again to check the current firmware version.



7. Your firmware upgrade is now completed.