



Quick Installation Guide  

TEW-624UB
3.01

Table of Contents

English	1
1. Before You Start	1
2. How to Install	2
3. Using the Wireless Adapter	3
Troubleshooting	5



Package Contents

- TEW-624UB
- Utility & Driver CD-ROM
- Multi-Language Quick Installation Guide

System Requirements

- USB port: 2.0 or 1.1
- CD-ROM Drive
- CPU: 300MHz or above / 800MHz or above (Windows Vista)
- Memory: 256MB RAM or above / 512MB RAM or above (Windows Vista)
- Windows 7/Vista/XP/2000

2. How to Install

Important! DO NOT install the USB Adapter in the computer until instructed to do so.


For Windows Users

1. Insert the **Utility & Driver CD-ROM** into your computer's CD-ROM Drive.


2. Click **Run autorun.exe** (Windows Vista only).




3. Click **Install Drivers**.



4. Click **Next**. Then follow the **InstallShield Wizard** instructions.



5. Click **Finish**.



6. Connect the wireless adapter to an available USB port on your computer.



7. Drivers will install automatically.


Your installation is now complete.

3. Using the Wireless Adapter


1. On the bottom right-hand corner of the screen, double-click on the **TEW-624UB manager** icon.



2. Click **Site Survey**, select the SSID and then click **Connect**.



3. If Encryption is enabled on your access point, select the **Authentication** type, select the **Encryption** mode, enter the encryption key and then click **Apply**.



Wireless configuration is complete

For detailed information regarding the **TEW-624UB** configuration and advanced settings, please refer to the Troubleshooting section, User's Guide on the Utility & Driver CD-ROM, or TRENDnet's website at <http://www.trendnet.com>.

Register Your Product

To ensure the highest level of customer service and support, please take a moment to register your product Online at: www.trendnet.com/register

Thank you for choosing TRENDnet

1. I inserted the Utility & Driver CD-ROM into my computer's CD-ROM Drive and the installation menu does not appear automatically. What should I do?

For Windows 2000/XP, if the installation menu does not appear automatically, click **Start**, click **Run**, and type **D:\autorun.exe** where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard. For Windows Vista, if the installation menu does not appear automatically, click **Start**, click the **Start Search** box, and type **D:\autorun.exe** where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard.

2. I completed all the steps in the quick installation guide, but my Wireless USB Adapter is not connecting to my access point. What should I do?

1. Verify that the **SSID** matches your wireless router or access point's **SSID**
2. Please check with your network administrator for security key in order to access a secured wireless access point or router. Please refer to the User's Guide for more information regarding wireless network security.
3. Check your TCP/IP properties to ensure that Obtain an IP address automatically is selected.
4. Double-click the TEW-624UB Manager icon, click **Site Survey** and then click **Refresh** to check and see if there are any available wireless networks listed.

3. Windows is unable to recognize my hardware. What should I do?

1. Make sure your computer meets the minimum requirements as specified in Section 1 of this quick installation guide.
2. You must complete the installation of the TEW-624UB Manager (as described in Section 2) before connecting the Wireless USB Adapter to your computer.
3. Connect the Wireless USB Adapter to a different USB port on your computer.

4. I cannot open the TEW-624UB Manager. What should I do?

Access your device manager to make sure the adapter is installed properly. If you see a networking device with a yellow question mark or exclamation point, you will need to reinstall the device and/or the drivers. To access the device manager on Windows 2000/XP, right-click **My Computer**, click **Properties**, click the **Hardware** tab, and then click **Device Manager**. To access the device manager on Windows Vista, right-click **Computer**, click **Properties** and then click **Device Manager**.

If you still encounter problems or have any questions regarding the **TEW-624UB**, please refer to the User's Guide included on the Utility & Driver CD-ROM or contact TRENDnet's Technical Support Department.

Declaration of Conformity



Company

Name:

TRENDware International, Inc.

Address

20675 Manhattan Place

Torrance, CA 90501

USA

Product:

Product Name:

300Mbps Wireless N USB 2.0 Adapter



Model Number:

TEW-624UB

Brand Name:

TRENDnet

Test Standard:

EN 300 328 V1.7.1: 10-2006

EN 301 489-1 V1.5.1: 11-2004

EN 301 489-17 V1.2.1: 08-2002

EN 50371: 2002

EN 50392: 2004

EN 60950-1: 2001

EN 60950-1/A11: 2004

Declaration:

The objects of declaration described above are compliant and following the provisions of the European R&TTE 1999/5/EC

I hereby declare that the products and devices mentioned above are consistent with the standards and provisions of the guidelines.

Sonny Su

Name (Full Name)

Director of Technology

Position / Title

February 1, 2009

Date

Legal Signature

Certifications

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.



Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com/register>