

TEW-IA040

**4dBi Omni Directional Indoor Antenna
Quick Installation Guide**

**Antenne intérieure omnidirectionnelle
Guide d'installation rapide**

**Omnidirektionale 4dBi-Zimmerantenne
Kurzanleitung zur Installation**

**Guía de instalación rápida de
la antena interior omnidireccional**

Version 01.14.05



TRENDnet[®]
TRENDware, USA
What's Next in Networking

Table of Contents

English	1
1. Prepare for Installation	1
2. Product Detail	2
3. Hardware Installation	3
Troubleshooting	4

English QIG

1. Prepare for Installation

Thank you for purchasing the TRENDnet TEW-IA040 4dBi Omni Directional Indoor Antenna.

This guide will help you set up your Omni Directional Indoor Antenna. Following the installations should be quick and easy. If you run into problems, please refer to the Troubleshooting section. If you need further technical support, please visit www.TRENDNET.com or call technical support by phone.

Verify Package Contents

Please make sure you have everything in the box:



2. Product Detail

The Omni Directional Indoor Antenna has a reverse SMA female connector that can either be connected to your Access Point or Wireless Network Adapter.



3. Hardware Installation

For Access Point, Wireless Router, or Wireless Card

1. Unscrew the antenna from your Wireless Access Point, Router, or Wireless Card.



2. Take the TEW-IA040 connector and connect it to either your Wireless Access Point, Router, or Wireless Card.



Your hardware installation is now complete.

Troubleshooting

Q1: Why do some of my wireless PCs receive a Wi-Fi signal, and other PCs get a weaker signal?

A1: The TEW-IA040 is an Omni Directional antenna and can only send and receive signals from a specified radius. You can adjust the position of the Wireless Access Point, extend your TEW-IA040 to an optimal location, or move those wireless PCs closer to the Wireless Access Point.

Q2: My access point indicates that it is receiving power, and my laptop is within range of the TEW-IA040. However, my laptop does not receive any signals from my access point.

A2: Make sure that you properly connect the antenna to the Wi-Fi Access Point. (See. 3. Hardware Installation)

Q3: Why won't the TEW-IA040 work with my IEEE 802.11a Wireless Router or Wireless Card?

A3: The TEW-IA040 is designed only for IEEE 802.11b or 802.11g Wireless Access Points or Wireless Cards. Please use the TEW-IA040 with compatible wireless devices.

Q4: Is it necessary to use the tapping screws or the wall anchors that come with the TEW-IA040?

A4: It is only necessary if you decide to mount the TEW-IA040 at a permanent location. Use discretion when attaching mounting brackets to the TEW-IA040.

If you have any questions regarding the TEW-IA040 4dBi Omni Directional Indoor Antenna, please contact Trendware Technical Support Department.

Contact Technical Support

Telephone: +1-310-626-6252
Fax: +1-310-626-6267
Website: www.TRENDNET.com
E-mail: support@trendware.com

Technical Support Hours

7:00AM ~ 6:00PM, Monday through Friday
Pacific Standard Time (except holidays)

Certifications

This equipment has been tested and found to comply with FCC and CE Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received including interference that may cause undesired operation.





Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDware's website at <http://www.TRENDNET.com>

TRENDware International, Inc.
3135 Kashiwa Street
Torrance, CA 90505

<http://www.TRENDNET.com>