

Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the switch configuration page
Default URL/IP address <http://192.168.10.200>
Default User Name: admin Default Password: admin
4. Navigate to the **Tools** section and click on **Firmware Upgrade**.
5. Under the **Image Select** section next to **Firmware File**, click **Browse** or **Choose File** and select the firmware file (.fw) from the extracted files.
6. Click the **Upgrade** button to start the firmware upgrade process.



The screenshot shows a web interface for firmware upgrade. At the top, the title "Firmware Upgrade" is displayed in a large, bold, black font. Below the title is a dark gray header bar with the text "Image Select" in white. Underneath the header bar is a light gray section containing a text input field labeled "Firmware File". To the right of the input field is a button labeled "Choose File" and the text "No file chosen". Below the input field and button is a blue button labeled "Upgrade". At the bottom of the section, there is a note in italics: "Note: System will reboot automatically after burning image to flash."

7. Wait until the firmware upload has completed and the device reboots.
8. The firmware upgrade is complete.