


Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the switch configuration page
Default URL/IP address <http://192.168.10.200>
Default User Name: admin Default Password: admin
4. Navigate to the **Management** section, click on **Maintenance**, and click on **Firmware**.
5. Under the **Upgrade Firmware** section, click **Browse** or **Choose File** and select firmware file (file name with ".fw" extension at the end) from the extracted files and click the **Upgrade** button to start the firmware upgrade process.



6. Wait until the firmware upload has completed and the device reboots.
7. The firmware upgrade is completed.