



TV-IP743SIC Firmware Upgrade Instruction

TRENDnet may periodically release firmware upgrades that might add features or fix problems associated with your TRENDnet model and version. To find out if there is a firmware upgrade available for your device, please check your TRENDnet model and version using the link.


<http://www.trendnet.com/support/>




1. If a firmware upgrade is available, download the firmware to your computer by click .





2. Firmware upgrade is an autonomous process which cannot be interrupted. Make sure your power supply and network connection will not be disturbed during firmware upgrade. Click **Continue with Download**.




3. Download the file to your computer. Click **Save As**, then choose the folder you want to save the file.






4. Right click on the downloaded file and select **Extract All** or **Extract Here** option. Make sure to remember the location where the extracted file is saved will be saved.




5. Log into the TV-IP743SIC with Bonjour, UPnP or the IP address.



6. Click on **Setup > Tools** and then **Firmware Upgrade**



7. Click **Browse...** and navigate to the folder on your computer in which the unzipped firmware file (.bin) is.




8. Located and select it the firmware file. Click **Open**.
9. Click **Upload** and wait until the firmware upload completed and the device reboot.
10. The firmware upgrade is completed.

Reset to Factory Default Settings

Not all the configuration files can be carried over to different versions of firmware. It is recommended that you reset configurations to the factory default and configure you TV-IP743SIC from the fresh start again.

To reset TV-IP743SIC configuration back to factory default, click **Reset** in this page. All configurations will be set back to its original default settings.



August 1, 2014

V1.0