TRENDNET

Quick Installation Guide

TEW-429UF

Table of Contents

1. Before You Start

	Package Content
	• TEW-429UF • CD-ROM • Quick Installation Guide • USB Cable

System Requirements

1. USB enabled computer
2. 300 MHz processor and 128 MB of memory (Recommended)
3. A minimum of 20MB of hard disk space.
4. CD-ROM drive
5. 802.11g or 802.11b Access Point (for Infrastructure Mode) or another 802.11g wireless adapter (for Ad-Hoc/Peer-to-Peer networking mode).
6. Windows 98SE/ME/2000/XP

108Mbps High Speed
802.11g Wireless Access Point
(TEW-450APB)

108Mbps High Speed 802.11g
Wireless Access Point
(TEW-453APB)

108Mbps 802.11a+g
Wireless Access Point
(TEW-510APB)

54Mbps 802.11g
Wireless Access Point
(TEW-430APB)

108Mbps 802.11g MIMO
Wireless Access Point
(TEW-610APB)

**802.11g Wireless and 512MB Flash Memory
Combo USB Adapter with HotSpot Detector**
(TEW-429UF)

detected ──── connected   *Laptop/PC is not required to detect HotSpots

Note: Please turn on your computer and follow the instructions below.

1. Connect the TEW-429UF into your computer's USB port.

2. Click **Install Utility & Driver.**

3. Click **Next** for each installation step and click **Install.**

Note: TRENDnet's Wireless Adapters have been fully tested under all supported Windows Operating Systems and have been approved for their functionality.

4. Click **Continue Anyway** or Click **Yes**.

5. Click **Finish.**

6. Click **Next**.

7. Click **Continue Anyway** or Click **Yes.**

8. Click **Finish.**

3. Using the Wireless Adapter

Note: We recommend that you restart your computer before using the TEW-429UF.

1. Double-click the wireless icon on your system tray.

2. Click **Site Survey**, click **Refresh**, and select the desired access point. Click **Connect**.

3. Click **OK.**

4. Please verify your connection status.

Your installation is now complete.

Note: For more detail on advanced features, please consult the User's Guide.

Q1: I completed all the steps in the quick installation guide, but my wireless USB Adapter isn't connecting to my access point. What should I do?

A1: First, you should verify that the Network SSID matches your wireless router or access point's SSID. Second, you should check your TCP/IP properties to ensure that Obtain an IP address automatically is selected. Third, you can click on the Site Survey link to check and see if there are any available wireless networks listed.

Q2: Windows is unable to recognize my hardware. What should I do?

A2: Make sure your computer meets the minimum requirements as specified in Section 1 of this quick installation guide. Also, you must install the wireless configuration utility before connecting the wireless USB Adapter.

Q3: I cannot open the wireless configuration utility. What should I do?

A3: Go to your device manager (control panel → system) to make sure the adapter is installed properly. If you see a networking device with a yellow question mark or exclamation point, you will need to reinstall the device and/or the drivers.

If you still encounter problems, please refer to the User's Guide CD-ROM or contact technical support.

TRENDnet

TRENDnet Technical Support

US/Canada Support Center

Contact
Telephone: 1(866) 845-3673
Email: support@trendnet.com

Tech Support Hours
24/7 Toll Free Tech Support

24/7
Technical Support 365 Technical Support 365

European Support Center

Contact
Telephone:
Deutsch : +49 (0) 6331 / 268-460
Français : +49 (0) 6331 / 268-461
0800-90-71-61 (numéro vert)
Español : +49 (0) 6331 / 268-462
English : +49 (0) 6331 / 268-463
Italiano : +49 (0) 6331 / 268-464
Dutch : +49 (0) 6331 / 268-465
Fax: +49 (0) 6331 / 268-466

Tech Support Hours
8:00am - 6:00pm
Middle European Time
Monday - Friday

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at http://www.trendnet.com

TRENDnet

3135 Kashiwa Street
Torrance, CA 90505
USA