



Quick Installation Guide



Table of Contents

Français	1
1. Avant de commencer	1
2. Procéder à l'installation	2
3. Impression	7
4. Faxer	8
5. Scannage	9
Troubleshooting	10



Contenu de l'emballage

- TE100-MP1UN
- CD-ROM (contenant l'utilitaire et les pilotes)
- Guide d'installation rapide en plusieurs langues
- · Adaptateur secteur (12V,1A)

Vérification de l'équipement

• D'un lecteur de CD-ROM


SE supportés	Microprocesseur	Mémoire
Windows 7 (32-bit)	1GHz ou supérieur	1GB RAM ou supérieur
Windows Vista (32-bit)	800MHz ou supérieur	512MB RAM ou supérieur
Windows XP (32-bit) / 2003 Server / 2000	300MHz ou supérieur	256MB RAM ou supérieur

Remarque:


- 1. Ne suivez les instructions suivantes que si vous en avez reçu la consigne :
 - 1. Installez l'utilitaire
 - 2. Branchez l'imprimante au serveur d'impression
 - 3. Branchez l'imprimante au serveur d'impression
- L'utilitaire doit être installé sur chaque ordinateur afin d'utiliser votre imprimante multifonction.

 Intallez les pilotes d'imprimante sur votre PC. Eteignez ensuite l'imprimante et débranchez-la de votre ordinateur.

<u>Remarque:</u> Veuillez consulter le manuel de votre imprimante pour les instructions d'installation de l'imprimante.



3. Cliquez Run Autorun.exe (Windows Vista uniquement).



4. Cliquez sur Install Utility. Et cliquez sur Setup Wizard.



5. Connectez l'imprimante USB au port USB du serveur d'impression. Et Cliquez sur OK.



- Branchez un câble réseau RJ-45 entre le Switch/Routeur et le port LAN du serveur d'impression.
- Branchez un câble réseau RJ-45 entre le switch/routeur et le port Ethernet de votre ordinateur et cliquez sur OK.
- Press Server State

 Print Server

 Print Server

 (i) Correct joins for Serve In Review in Review in Review

 Print Server

 (ii) Correct joins for Serve In Review in Review in Review

 (iii) Print City Server

 (iii) Print City Server

 (iii) Print City Server

 (iii) Print City Server

 (iii) Death (iii) or North Intelligency (iii) Out and Server

 (iii) Death (iii) or North Intelligency (iii) Out and Server

 (iii) Death (iii) or North Intelligency (iii) Out and Server

 (iii) Death (iii) or North Intelligency (iii) Out and Server

 (iii) Death (iii) or North Intelligency (iii) Out and Server

 (iii) Death (iii) or North Intelligency (iii) Out and Server

 (iii) Death (iii) or North Intelligency (iii) Out and Server

 (iii) Death (iii) or North Intelligency (iii) Out and Server

 (iii) Death (iii) or North Intelligency (iii) Out and Server

 (iii) Death (iii) Out or North Intelligency (iii) Out and Server

 (iii) Death (iii) Out or North Intelligency (iii) Out and Server

 (iii) Death (iii) Out or North Intelligency (iii) O





 Branchez l'adaptateur secteur AC au serveur d'impression et à une prise de courant. Et Cliquez sur OK.




 Vérifiez que le voyant Status allumé et que le voyant Error est éteint sur le serveur 'impression. Cliquez ensuite sur Yes.










Votre configuration est à présent terminée


Si vous désirez des informations détaillées sur la configuration et les paramètres avancés du TE100-MP1UN, veuillez consulter la rubrique Dépannage, le guide de l'utilisateur sur CD-ROM ou le site Internet de TRENDnet sur https://www.trendnet.com.

Enregistrez votre produit

Afin d'être sûr de recevoir le meilleur niveau de service clientèle et le meilleur support possibles, veuillez prendre le temps d'enregistrer votre produit en ligne sur: www.trendnet.com/register Nous vous remercions d'avoir choisi TRENDnet.


<u>Remarque:</u> Un seul utilisateur peut utiliser le serveur à la fois. Une fois qu'un utilisateur a terminer d'utiliser le serveur d'impression, un autre utilisateur peut s'en servir.





Remarque: Un seul utilisateur peut utiliser le serveur à la fois. Une fois qu'un utilisateur

<u>Remarque:</u> Un seul utilisateur peut utiliser le serveur à la fois. Une fois qu'un utilisateur a terminer d'utiliser le serveur d'impression, un autre utilisateur peut s'en servir.



Troubleshooting

- 1. I inserted the Driver CD-ROM into my computer's CD-ROM Drive and the installation menu does not appear automatically. What should I do?
 - 1. For Windows 7, if the installation menu does not appear automatically, click on the Windows Icon on the bottom left hand corner of the screen,, click the "Search programs and files" box, and type D:\autorun.exe, where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Driver, and then press the ENTER key on your keyboard
 - 2. For Windows Vista, if the installation menu does not appear automatically, click Start, click the Start Search box, and type D:\autorun.exe where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard.
 - 3. For Windows 2000/XP, if the installation menu does not appear automatically, click Start, click Run, and type D:\autorun where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard.
- 2. The setup wizard/utility does not detect the Print Server and/or printer/storage device. What should I do?
 - Double check your hardware connections; make sure that the Print Server and printer are powered ON and are properly connected. Make sure the RJ-45 network cable is securely connected to the Print Server and Switch/Router.
 - Disable any software firewall programs such as ZoneAlarm or Norton Internet Security. If your computer is running Windows 7, Vista or XP, disable the built-in firewall.
 - 3. Click Refresh.
 - 4. Power cycle the Print Server. Unplug the power to the Print Server, wait 15 seconds, then plug the Print Server back in.
- 3. The setup wizard/utility does not detect my printer device. What should I do?
 - 1. Make sure the printer is powered on and properly connected to the Print Server
 - 2. Connect the printer with another USB cable.
 - 3. Reset the print server. Take a pin or paperclip and press the reset button on the print server for 15 seconds, then let go.

- 4. I am unable to print to my Print Server. What should I do?
 - 1. Make sure you follow the exact steps for installing the Print Server in section 2.
 - Make sure to right click on the print server in the utility and click connect. If another user is using the print server, you must wait until the user is finished using it.
 - 3. If you are connected to the print server and are idled for a couple of minutes, a warning message appears. If you do not respond within a minute, you will be automatically disconnected from the print server. You must connect to the print server again.
- 5. I can print a test page, but I cannot print anything from Microsoft Word or other applications.

Make sure to set the newly installed network printer as your default printer. Click Start and then click Printers & Faxes, verify that your printer icon has a check on it

- 6. I configured my Print Server to automatically receive an IP Address from a DHCP server, and now I cannot go into the Print Server's web utility. Open the print server setup wizard (See 3. Configure the Print Server) to locate your Print Server's IP Address.
- 7. Is there a way to force a computer to give up ownership to the print server? If the user has been idled for 5 minutes, the user will be automatically disconnected. You can also force a computer to give up owner ship to by unplugging the power to the print server and plug the power back in.

If you still encounter problems or have any questions regarding the TE100-MP1UN, please refer to the User's Guide included on the Utility CD-ROM or contact TRENDnet's Technical Support Department.

Certifications

This equipment has been tested and found to comply with FCC and CE Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.





Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ADVERTENCIA

En todos nuestros equipos se mencionan claramente las caracteristicas del adaptador de alimentacón necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños fisicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energia electrica domiciliaria existente en el pais o zona de instalación.



Product Warranty Registration

Please take a moment to register your product online. Go to TRENDnet's website at http://www.trendnet.com/register