# **TEW-424UB**

54Mbps 802.11g Wireless USB 2.0 Adapter Quick Installation Guide

Guide d'installation rapide du 54Mbps 802.11g USB 2.0 sans fil

Anleitung zur Schnellinstallation des 802.11g USB-2.0-Adapter mit 54MBit/s

Guía de Instalación Rápida Adaptador inalámbrico USB 2.0 802.11g a 54Mbps

Руководство по быстрой установке адаптера беспроводной связи 54 Мбит/с 802.11g Wireless USB 2.0

Version 02.15.2005





# **Table of Contents**

English	1
1. Prepare for Installation	1
2. Install Hardware	2
3. Install Wireless Configuration Utility	3
4 Install Drivers	5
5. Wireless Configuration	13
Troubleshooting	17

## **English QIG**

## 1. Prepare for Installation

Thank you for purchasing the TEW-424UB. Your new 54Mbps 802.11g Wireless USB 2.0 Adapter will allow you to connect to 802.11g or 802.11b networks and begin wirelessly sharing the Internet, files, and other resources.

This guide will help you set up and configure your Wireless USB Adapter. Following this installation should be quick and easy. If you run into problems, please refer to the Troubleshooting section or the more detailed installation procedures on the User's Guide CD-ROM. If you need further technical support, please visit www.TRENDNET.com or call technical support by phone.

## **Verify Package Contents**

Please make sure you have everything in the box:



## **Minimum Hardware Requirements**

Before installing this 802.11g Wireless USB Adapter, you should have a:

- 1. USB enabled computer
- 2. 300 MHz processor and 32 MB of memory (Recommended)
- 3. CD-ROM drive
- **4.** 802.11g or 802.11b Access Point (for Infrastructure Mode) or another 802.11g wireless adapter (for Ad-Hoc/Peer-to-Peer networking mode).
- 5. Windows 98SE/ME/2000/XP

**Note:** Do not connect the Wireless USB Adapter to your computer until you have finished installing the Utility and Driver.

## 2. Install Hardware

The TEW-424UB is hot-pluggable. You can connect or disconnect the TEW-424UB while the computer is on.

Connect the TEW-424UB Wireless USB Adapter to your computer's USB port.

<u>Note:</u> you can use the included USB extension cable for your convenience to extend the cable connection between your computer and the TEW-424UB.



## 3. Install Wireless Configuration Utility

## Windows 98SE/ME/2000/XP


 Insert the TEW-424UB CD-ROM into your computer's CD-ROM drive; the installation menu window will appear automatically. If the window does not appear automatically, click Start, click Run, and type E:\Autorun.exe in the text-field. Click OK.

<u>Note:</u> Replace "E" in "E:\Autorun.exe" with whichever letter is assigned to your CD-ROM drive.


2. On the Installation Menu, click Install Utility.




- **3.** Follow the Install Shield Wizard's instructions to install the wireless configuration utility.
- 4. Click Next.




#### 5. Click Next.



### 6. Click Next.




#### 7. Click Finish.




## 4. Install Drivers

## Windows 98SE


 After installing the utility software, connect the Wireless USB Adapter to your computer's USB port. The "Add New Hardware Wizard" will appear. Verify that the TEW-424UB CD-ROM is in your CD-ROM drive. Then click Next.




Click Search for the best driver for your device (Recommended). Click Next.



3. Click Specify a location, and type in E:\Drivers\Windows 98. Click Next.




4. Click Next.



5. Click OK.



#### 6. Click Finish.



#### 7. Click Yes.



**8.** After your computer reboots, select the country domain that applies to you, and click **OK**.



#### 9. Click Yes.



<u>Note:</u> After driver installation is complete, the wireless icon will appear in your system tray (next to the clock on the bottom right corner of your screen). If it does not appear, restart your computer. **Go to section 5 Wireless Configuration.** 

#### **Windows Me**

After installing the utility software, connect the Wireless USB Adapter to your computer's USB port.

1. Select the country domain that applies to you and click **OK**.




## 2. Click Yes.



## Windows 2000

- After installing the utility software, connect the Wireless USB Adapter to your computer's USB port. Windows will detect new hardware and load the driver automatically.
- When the Digital Signature Not Found Window appears, click Yes to continue.



**NOTE:** TRENDnet's Wireless Adapters have been fully tested under all supported Windows Operating Systems and have been approved for their functionality.

3. Select the country domain that applies to you and click **OK**.



#### 4. Click Yes.




<u>Note:</u> After clicking Yes, the wireless icon will appear in your system tray (next to the clock on the bottom right corner of your screen). If it does not appear, restart your computer. **Go to section 5 Wireless Configuration.** 

## **Windows XP**


 After installing the utility software, connect the Wireless USB Adapter to your computer's USB port. The "Found New Hardware Wizard" will appear. Verify that Install the software automatically is selected and that the TEW-424UB CD-ROM is in your CD-ROM drive. Then click Next.



2. Select c:\windows\inf\sis163u.inf and Click Next.




A warning message will tell you that the device you're installing has not yet been certified for Windows XP compatibility. Click Continue Anyway.



**NOTE:** TRENDnet's Wireless Adapters have been fully tested under all supported Windows Operating Systems and have been approved for their functionality.

4. Select the country domain that applies to you and click OK.



5. Click Yes.



**6.** The "Found New Hardware Wizard" will tell you that it has finished installing the software for your TEW-424UB. Click **Finish**.



<u>Note:</u> After clicking **Finish**, the wireless icon will appear in your system tray (next to the clock on the bottom right corner of your screen). If it does not appear, restart your computer. **Go to section 5 Wireless Configuration.** 


## 5. Wireless Configuration

# <u>Infrastructure Mode (PC-to-Access Point connection)</u>


 Double-click the wireless computer icon in your system tray (next to the clock in the bottom right corner of your screen).




Click the Configuration Tab. Select Infrastructure (Access Point) as the Network Mode.



Enter a Network SSID that matches the SSID of your Access Point. (If you are unsure of your Access Point's SSID, refer to your Access Point settings) Click Apply.



Click the Status tab; if you see connection information, your card's wireless configuration is complete.



## **Ad-Hoc Mode (PC-to-PC connection)**


 Double-click the wireless computer icon in your system tray (next to the clock in the bottom right corner of your screen).




Click the Configuration Tab. Select 802.11 Ad-Hoc (Computer to Computer) as the Network Mode.



Enter a Network SSID that matches the SSID of the wireless card you will be connecting to. (If you are unsure of your other wireless card's SSID, refer to that card's settings)



- Because you are configuring an Ad-Hoc network, you must select a Channel then click Apply.
- Click the Status tab; if you see connection information, your card's wireless configuration is complete. (Ad-hoc mode requires at least 2 wireless adapters to establish the connection)



Your Wireless Network Adapter is now configured and ready for use!

## **Troubleshooting**

# Q1: I completed all the steps in the quick installation guide, but my wireless USB Adapter isn't connecting to my access point. What should I do?

A1: First, you should first verify that the Network SSID matches your wireless router or access point's SSID. Second, you should check your TCP/IP properties to ensure that Obtain an IP address automatically is selected. Third, you can click on the Site Survey link to check and see if there are any available wireless networks listed.

#### Q2: Windows is unable to recognize my hardware. What should I do?

**A2:** Make sure your computer meets the minimum requirements as specified in Section 1 of this quick installation guide. Also, you must install the wireless c onfiguration utility (as described in Section 3) before connecting the wireless USB Adapter.

#### Q3: I cannot open the wireless configuration utility. What should I do?

A3: Go to your device manager (control panel → system) to make sure the adapter is installed properly. If you see a networking device with a yellow question mark or exclamation point, you will need to reinstall the device and/or the drivers.

If you still encounter problems, please refer to the User's Guide CD-ROM or contact technical support.

#### Certifications

This equipment has been tested and found to comply with FCC and CE Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.





## **Product Warranty Registration**

Please take a moment to register your product online. Go to TRENDware's website at http://www.TRENDNET.com

#### TRENDnet Technical Support **US/Canada Support Center European Support Center** Contact Contact **Telephone:** 1(310) 626-6252 Telephone 1(310) 626-6267 Deutsch: +49 (0) 6331 / 268-460 Email: support@trendnet.com Français: +49 (0) 6331 / 268-461 Español: +49 (0) 6331 / 268-462 Tech Support Hours English: +49 (0) 6331 / 268-463 7:30am - 6:00pm Pacific Standard Time Italiano : +49 (0) 6331 / 268-464 Monday - Friday : +49 (0) 6331 / 268-465 Dutch Fax: +49 (0) 6331 / 268-466 **Tech Support Hours** 8:00am - 6:00pm Middle European Time Monday - Friday

## TRENDware International, Inc.

3135 Kashiwa Street. Torrance, CA 90505

http://www.TRENDNET.com