



Fiber Converters

TFC-1000 Series

- Lühike paigaldusjuhend (1)
- Technical Specifications (6)
- Tõrkeotsing (7)

1. Enne alustamist

Pakendi sisu

- Fiiberkonverteri
- Mitme keelne lühike paigaldusjuhend
- Toiteplokk

Kui ükskõik milline eespool sisu on puudu, võtke palun ühendust oma edasimüüjaga

Miinimumnõuded

- Keskkond, mis on üpris jahe ja kuiv
- Keskkond, mis on vaba tugevatest elektromagnetilistest väljadest (näiteks, elektrimootoritest), vibratsioonist, tolmust ja otsesest päikesevalgusest
- TFC-1600 raamistik (valikuline) asetada tasasele ja vastupidavale alusele, mis suudab toetada fiiberkonverterite raskust.
- 1000Mbps Gigabit Ethernet Switch
- Multi-mode või Single-mode fiiberkaablid
- Cat. 5e, 6 RJ-45 Etherneti kaablid


Lisavarustus

- EIA standardne 19" seadmekapp
- TFC-1600 raamistik
- Mini-GBIC moodul (näiteks TEG-MGBSX, TEG-MGBS10, TEG-MGBS40, TEG-MGBS80, TEG-MGBS10D35, TEG-MGBS40D35) Mini-GBIC pesasse (ainult TFC-1000MGB/TFC-1000MGA)

2. Riistvara paigaldamine

Kahe eraldiseisva fiiberkonverteri paigaldamine

1. Ühendage RJ-45 Etherneti kaabel fiiberkonverteri Etherneti pordist mõne teie switchi (näiteks TEG-S24Dg) Etherneti porti.



2. Ühendage fiiberkaabel fiiberkonverteriga.



3. Ühendage toiteplokk fiiberkonverteri taha.



Märkus:

1. TFC-1000MSC / S20/ S50 / S70 konverteritel, peavad TX ja RX kaablid olema teisel pool vastupidiselt.
2. Kaabeldus
 - a. Multi-Mode optiline kaabel: TFC-1000MSC, TFC-1000MGB koos TEG-MGBSX mooduliga
 - b. Single-Mode optiline kaabel: TFC-1000S20, TFC-1000S50, TFC-1000S70, TFC-1000MGB/TFC-1000MGA koos TEG-MGBS10/TEG-MGBS40/TEG-MGBS80 mooduliga
 - c. Ühekiuline optiline kaabel : TFC-1000S10D3, TFC-1000S10D5, TFC-1000S40D3, TFC-1000S40D5, TFC-1000MGB/TFC-1000MGA koos TEG-MGBS10D3/TEG-MGBS10D5/TEG-MGBS40D3/TEG-MGBS40D5 mooduliga

Fiiberkonverteri paigaldamine šassiisse

1. Kruvige šassiil soovitud kohas lahti katteplaat.



2. Keerake fiiberkonverteri küljest lahti kinnituskrugi ja eemaldage metallist kate.



3. Asetage meedikonverter vabasse pesasse ja kinnitage kruviga.



Paigaldamine on lõppenud.

3. LEDid ja DIP lülitid

LEDid			
LED	Värv	Jada	Funktsioon
PWR (Power)	Roheline	Pidev	Seade on sisse lülitatud
	Väljas	Väljas	Seade on välja lülitatud
LINK/ ACT	Green	Pidev	2000Mbps (Full Duplex) ühenduses (pordi kohta)
	Roheline	Vilgub	2000Mbps Full Duplex Andmete edastamine või vastuvõtmine (pordi kohta)
	Väljas	Väljas	Link on katkestatud

DIP lülitid		
lülit	Tegevus	Funktsioon
1	Sees	TX Forced Mode
	Väljas	TX Auto-Negotiation
2	Sees	LLR Enable
	Väljas	LLR Disable

Märkus:

1. Peale DIP lülite asendite muutmist tehke fiiberkonverterile algaadimine.
2. LLR tähendab Link Loss Return (kaotatud lingi tagastamine). Kui LLR on lubatud, siis fiiberportide saatja lülitub välja, kui ei suudeta avastada töötavat saatjaühendust. Kui üks optilistest ühendustes on halb ja kaardil on LLR lubatud, siis antakse teada, et puudub ühendus teise poolega. LRR võimaldab avastada vaid fiiberoptika pordi ühenduse probleeme. Kui LLR on sisselülitatud ühes fiiberkonverteris, siis teise poole fiiberkonverteris on vaja LRR ära keelata.

4. Technical Specifications

Power Budget									
Model Number	Media	Connectors	Wavelength	Optical Output Power (dBm)		Optical Input Power (dBm)		Power Budget	Distance
				Min.	Max.	Min. (Sensitivity)	Max.		
TFC-1000MSC	MMF	RJ-45/SC (Duplex)	850nm	-9.5	-4	-12.5	-13.5	7.5	220m (62.5/125µm) cable 550m (50/125 µm) cable
TFC-1000S20	MMF	RJ-45/SC (Duplex)	1310nm	-9.5	-3	-20	-3	11.5	20km
TFC-1000S50	MMF	RJ-45/SC (Duplex)	1550nm	-4	1	-23	-3	19	50km
TFC-1000S70	SMF	RJ-45/SC (Duplex)	1550nm	0	5	-24	-3	24	70km
TFC-1000S10D3	SMF	RJ-45/SC- (Simplex)	TX-1310nm/ RX-1550nm	-9	-3	-21	-3	12	10km
TFC-1000S10D5	SMF	RJ-45/SC- (Simplex)	TX-1550nm/ RX-1310nm	-9	-3	-21	-3	12	10km
TFC-1000S40D3	SMF	RJ-45/SC- (Simplex)	TX-1310nm/ RX-1550nm	-7	-2	-23	-2	16	40km
TFC-1000S40D5	SMF	RJ-45/SC- (Simplex)	TX-1550nm/ RX-1310nm	-7	-2	-23	-2	16	40km

1. Peale fiiberkonverteriga ühendamist ei hakka LEDid helenduma. Mida ma peaksin tegema?

1. Kontrollige, et pistikupesas on voolu.
2. Veenduge, et toiteplokk on kindlalt ühendatud fiiberkonverteri ja pistikupesaga.
3. Veenduge, et Ethernet ja fiiberkaablid on ühendatud.

2. Kõik LED'id helenduvad, aga ma ei saa ühendust. Mida ma peaksin tegema?

1. Veenduge, et te kasutate õiget fiiberkaablit (nt, mitme multi-mode fiiberkaabel multi-mode konverteriga; singel-mode fiiberkaabel singel-mode konverteriga).
2. Veenduge, et TX ja RX kaablid on teises fiiberühenduses vastupidiselt ühendatud (TFC-1000MSC, TFC-1000S20, TFC-1000S50, TFC-1000S70).
3. Lülitage fiiberkonverterid ja switchid välja. Oodake 15 sekundit ja siis ühendage switchid ja fiiberkonverterid tagasi.

3. Mis on maksimaalne kaugus, mida fiiberkonverter toetab?

Palun tutvuge 4. osas vahemaa andmetega.

Kui teil endiselt esineb probleeme või on küsimusi fiiber konverteri kohta, siis palun võtke ühendust TRENDneti tehnilise toe osakonnaga.

Declaration of Conformity



Company Information:

Company Name:
TRENDnet, Inc.

Company Address:
20675 Manhattan Place
Torrance, CA 90501
USA

Product Information:

Product Description:
1000Base-TX to 1000Base-SX/LX Fiber Converter



Model Number:
TFC-1000MSC, TFC-1000S20, TFC-1000S50, TFC-1000S70
TFC-1000MGB, TFC-1000MGA, TFC-1000S10D3,
TFC-1000S10D5 1000S40D3, TFC-1000S40D5

Brand name:
TRENDnet

Technical Standards:

EN 55022 : 2006 Class A
EN 61000-3-2 : 2006 Class A
EN 61000-3-3 : 1995 + A1 : 2001 + A2 : 2005
EN 55024 : 1998 + A1 : 2001 + A2 : 2003

Declaration:

The product is herewith confirmed to comply with the requirements of Directive 2004/108/EC of the Council (European Parliament) on the EMC directive and Energy-related products Directive 2009/125/EC.

I hereby declare that the products and devices mentioned above are consistent with the standards and provisions of the guidelines.

Sonny Su

Full Name

May 27, 2011

Date

Director of Technology

Position / Title

Signature

Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

Fiber Converters– 3 Years Limited Warranty

AC/DC Power Adapter, Cooling Fan, and Power Supply carry a 1 year warranty.

If a product does not operate as warranted during the applicable warranty period, TRENDnet shall reserve the right, at its expense, to repair or replace the defective product or part and deliver an equivalent product or part to the customer. The repair/replacement unit's warranty continues from the original date of purchase. All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of-purchase for their return policies.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product by any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase. Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued. An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment. Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees.

WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES,

EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California. Some TRENDnet products include software code written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL").

Go to <http://www.trendnet.com/gpl> or <http://www.trendnet.com> Download section and look for the desired TRENDnet product to access to the GPL Code or LGPL Code. These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. Please go to <http://www.gnu.org/licenses/gpl.txt> or <http://www.gnu.org/licenses/lgpl.txt> for specific terms of each license.



Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com/register>

Certifications

This equipment has been tested and found to comply with FCC and CE Rules.
Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.

TRENDnet
20675 Manhattan Place
Torrance, CA 90501. USA