



How to playback video recorded on TRENDnetView Pro software?




Launch the software by clicking on the short cut on your desktop after you install the TRENDnetView Pro.

1. Click on the  **Open Archive** button on tool bar.




2. Double click on the camera you want to playback the video.



Frequent Asked Video Playback Questions


Q: What the orange and purple lines on the time line mean?



A: Motion triggered video recording will be showed in orange. Recorded audio will be displayed in blue.


Q: Can I jump to the next or previous motion triggered recording when I am playing back the video?

A: Yes. Click **Seek to next motion** or **Seek to previous motion** button on the tool bar to skip the video.




Q: How can I skip certain amount of time of recording when I am playing back the video?

A: Select the time interval you want to skip from the drop down menu on the tool bar. Then, click **Seek Backward** or **Seek Forward** button to skip the video.



Q: How can I adjust the unit of time line to cover certain amount of time?

A: Select Time Line from tool bar and select the time span you want to fit. Or, zoom in and out to adjust the time unit.



Advanced Settings

For advanced features of TRENDnetView Pro software, please refer to the TRENDnetView Pro User's Guide on the CD.