




How to setup motion triggered recording on TRENDnetView Pro software?

After the camera installation, you can install the windows based TRENDnetView Pro software, which comes with the CD, to manage your TRENDnet network cameras. Click on **Install TRENDnetView Pro Software**.




Launch the software by clicking on the short cut on your desktop after you install the TRENDnetView Pro.


1. Right click on the camera you want to setup motion detection and then click on **Camera Setup Wizard**.




2. Click **Next** to start the wizard.




3. Select the camera you want to add motion detection and then click **Next**.




4. Click on **Next** to continue the setting.




5. Check the **Use motion detector for the stream being set up**. Then click **Properties**.




6. Select **Software Motion Detection Priority** and then click on **OK**.




7. Back to the setup wizard and click **Next**.




8. Select **Video** and **Video Motion Information** then click **Advanced Properties** to setup recording.




9. Select **Motion and Events** tab, check on **Enable motion controlled recording** and then click **Next**.




10. Back to the setup wizard and click **Next**.



11. Double check the camera information and then click **Next**.



12. Click **Finish** to quit the setup wizard.



Advanced Settings

For advanced features of TRENDnetView Pro software, please refer to the TRENDnetView Pro User's Guide on the CD.